## A Vocal Hex Dump For The KIM-1

William C. Clements, Jr. Dept. Of Chemical And Metallurgical Engineering The University Of Alabama

This article describes a program for the KIM-1 that begins at a given RAM address and pronounces the contents of successive locations, with appropriate pauses inserted for naturalness, just as a person would read off a list of hex words. It uses what is almost certainly the least expensive speech synthesis equipment and software now on the market; for about \$100, the single-board computer owner can experiment with computer-generated speech. The program given here is concerned with removing a little of the drudgery from proofreading programs in RAM. The program runs on a KIM-1 to which has been added a 6522 VIA and at least 1K of expansion RAM.

Personal computers surely are the ultimate in modern versatility, making everything from dungeons-and-dragons to home automation to self-instruction in computer science available to nearly everyone. But no matter how much fun it is to use the polished end result of one's programming, the checking of machine code to see if it was entered correctly remains pure drudgery, and the cleverest technology isn't likely to ever place it on a level with playing a rousing game of motorcycle racing with the computer. For those of us with video terminals but no printer, it can be especially irritating; one's eyes move up to the screen dump, down to the written program, up and down, kind of like watching a vertical tennis game, until the eyes have had it.

It would help to have someone read off the code from the screen so the programmer can keep his eyes on the paper. But another person isn't always available, and anyhow this is just the kind of work that computers were invented to handle, right? The only trouble is, most speech synthesizers are expensive, and are usually for the S-100 bus, not directly usable with the KIM or similar single-board machine. Now, thanks to Texas Instruments, Inc. and Dave Kemp of East Coast Micro Products, these objections have been neatly removed. The T-I Speak and Spell<sup>TM</sup>, an inexpensive (\$50 range) preprogrammed speech synthesizer computer was developed to teach kids to spell.¹ Its internal ROMs contain the coding to vocalize hundreds of words plus

several phrases, the letters of the alphabet, and the numerals. But it's more than a toy. The device has an internal edge connector intended for plugging in additional vocabulary ROMs, and the various control lines that operate the speech synthesizer are available there. East Coast Micro Products market a small interface kit, model SP-11, that plugs onto the edge connector, and performs the level shifting and parallel-to-serial conversion needed for interfacing the synthesizer to a computer. The whole thing fits into the battery compartment of the Speak and Spell™ making a very neat package. Along with the interface board, you get extensive support software, a detailed explanation of how the synthesizer works, and five demo programs written for the SYM computer. The software includes a program for pronouncing individual hex characters whose ASCII representation has been placed in the accumulator, and uses the 6522 VIA that the SYM uses for I/0.

As mentioned at the start of this article, my immediate goal in purchasing the SP-1 was to use it with a KIM to read out memory words. The listing gives the resulting program. The user begins execution at BEGIN, types the first RAM address on the TTY, and the program reads 256 locations out on the Speak and Spell<sup>TM</sup>. If you're checking fewer locations, just hit the reset key when you're through. If your program is longer, type in the next location and it will read you 256 more.

The comments in the listing should be self explanatory for the most part. Label references not defined in the listing (such as FPNT, OUTSPE, etc.) are mostly labels in the SP-1 software. GETBYT is a routine in the KIM monitor.

The SP-1 software is set up to use the 6522 Versatile Interface Adaptor on the SYM board, so unless you want to re-program extensively, your best bet is to add a 6522 to your KIM; you ought to have one anyhow if you're a serious KIMmer. Mine was already present on a VIDEO PLUS™ board that I use with my system1. If you don't have a VIA in your system, I suggest you refer to the articles listed in the footnotes3,4. It should not be hard to provide one. The SP-1 software resides entirely in the KIM on-board memory with one exception: the speech data dictionary provided with the software requires 770 bytes of continuous memory in addition to the 478 bytes required by the SP-1 support software and by the vocal dump routine. None of the code is selfmodifying, so you can relocate it at will, even into EPROM where it will become a valuable utility. The only memory that has to be RAM is the twelve-byte frame buffer which I located between \$17A0 and \$17AB. If you do relocate, take care to adjust the entries in TABLE. These are address pointers to entries in the speech dictionary supplied with the SP-1. The accompanying program listing assumes that the dictionary resides between \$2000 and \$2302 in expansion memory.

```
0010
                                   .BA $100
                 0020 ADLO
                                   .DE $A
                 0030 ADHI
                                   .DE $B
                 0035 SPNT
                                  .DE 2
                 0040 GETBYT
                                   .DE $1F9D
                 0050 FPNT
                                  .DE 4
                 0060 SPINIT
                                  .DE $200
                 0070 OUTSPE
                                   .DE $2D0
0100- 20 9D 1F
                 0080 BEGIN
                                  JSR GETBYT
                                                ;GET START
0103- 85 OB
                 0090
                                                ; ADDRESS
                                  STA *ADHI
0105- 20 9D 1F
                 0100
                                  JSR GETBYT
                                                ;FROM
0108- 85 OA
                 0110
                                  STA *ADLO
                                                ; KEYBOARD
010A- A9 A0
                 0120
                                  LDA #$A0
                                                ;SET FRAME
010C- 85 04
010E- A9 17
                 0130
                                  STA *FPNT
                                                ; POINTER
                 0140
                                  LDA #$17
                                                ;TO
0110- 85 05
                 0150
                                  STA *FPNT+1
                                                ;$17A0 (12 LOCS NEEDED)
0112- 20 00 02
0115- 20 2D 01
                 0160
                                  JSR SPINIT
                                                ;SET UP TIMERS
                 0170
                                  JSR PAUSE
                                                ; PAUSE BEFORE SPEAKING
0118- A0 FF
                                                :USE Y TO COUNT LOCS.
                 0180
                                  LDY #$FF
011A- C8
                 0190 LOOP
                                  INY
                                                : DUMPED
011B- 98
                 0200
                                  TYA
011C- 48
                 0210
                                  PHA
011D- B1 0A
                 0220
                                  LDA (ADLO), Y ; GET CURRENT CONTENTS FOR DUMP
011F- 20 31 01
                 0230
                                  JSR SAY
                                                ; PRONOUNCE CONTENTS;
0122- 20 2D 01
                 0240
                                  JSR PAUSE
                                                THEN PAUSE
0125- 68
                 0250
                                  PLA
0126- A8
                 0260
                                  TAY
0127- C9 FF
                 0270
                                  CMP #$FF
0129- D0 EF
                 0280
                                  BNE LOOP
                                                ;LOOP 256 TIMES
012B- F0 D3
                 0290
                                  BEQ BEGIN
                                                GET NEW START
012D- A2 20
                 0300 PAUSE
                                  LDX #$20
                                                ; SET POINTER FOR PAUSE
012F- D0 0E
                 0310
                                  BNE SP1
                                                ; BRANCH TO SPEECH PAUSE
0131- 48
                 0320 SAY
                                  PHA
                                                ; SAVE CONTENTS
0132- 29 FO
                                                ;GET HIGH-ORDER NYBBLE
                 0330
                                  AND #SF0
0134- 4A
                 0340
                                  LSR A
                                                ; FORM INDEX
0135- 4A
                 0.350
                                  LSR A
                                                ; INTO ADDRESS TABLE
0136- 4A
                 0360
                                  LSR A
0137- 20 3E 01
                0370
                                  JSR SPEAK
                                                ;SPEAK FIRST CHARACTER
013A- 68
                 0380
                                  PLA
013B- 29 OF
                 0390
                                  AND #$F
                                                GET LOW-ORDER NYBBLE
013D- 0A
                 0400
                                  ASL A
                                                ; FORM INDEX
013E- AA
                 0410 SPEAK
                                  TAX
                                                ; AND FALL THROUGH
013F- BD 4C 01
                 0420 SPI
                                  LDA TABLE; X ; TO SPEAK IT
0142- 85 02
                 0430
                                  STA *SPNT
0144- BD 4D 01
                 0440
                                  LDA TABLE+1;X
0147- 85 03
                 0450
                                  STA *SPNT+1
0149- 4C D0 02
                 0460
                                  JMP OUTSPE
014C- 00 20 49
                 0470 TABLE
                                  .BY 0 $20 $49 $20 $76 $20 $9F $20 ;ADDRESS
                                  TABLE FOR
014F- 20 76 20
0152- 9F 20
0154- DB 20 11
                 0480
                                  .BY $DB $20 $11 $21 $52 $21 $86 $21 ;
                                  SPEECH DICTIONARY
0157- 21 52 21
015A- 86 21
015C- B7 21 DA
                0490
                                 .BY $B7 $21 $DA $21 $16 $22 $36 $22
015F- 21 16 22
0162- 36 22
0164- 61 22 8E
                0500
                                 .BY $61 $22 $8E $22 $B5 $22 $D0 $22 $FD $22
0167- 22 B5 22
```

The SP-1 utilities can be used for many other purposes. A great deal of information and some references concerned with speech synthesis using Linear Predictive Coding techniques are given in the literature supplied with the kit. With this material, you can make your KIM as talkative as you wish!

016A- D0 22 FD 016D- 22

0510

-EN

LABEL FILE: [ / = EXTERNAL ]

/ADLO=000A /ADHI=000B /SPNT=0002 /GETBYT=1F9D /FPNT=0004 /SPINIT=0200 /OUTSPE=02D0 BEGIN=0100 LOOP=011A PAUSE=012D SAY=0131 SPEAK=013E SP1=013F TABLE=014C //0000;016E;016E

## Footnote.

1. Speak and Spell is a trademark of Texas Instruments, Inc. VIDEO PLUS is a trademark of The Computerist, Inc.

- 2. East Coast Micro Products, 1307 Beltram Ct., Odenton, Md. 21113.
- 3. Sec 6502 User Notes, No. 13, p. 16 for information about adding a 6522 I/O board.
- 4. See MICRO, No. 17, pp. 27-39 for a general description of the 6522.