

ASK™ VIDEO PLUS Software

**“Glass Teletype” Software
for use with the
AIM - SYM - KIM
and the
VIDEO PLUS**

Description of the ASK VIDEO PLUS Software

This software package makes the VIDEO PLUS much easier to interface with the AIM, the SYM and the KIM. It has been developed in response to a number of requests and suggestions from VIDEO PLUS owners. The basic features of this new package are:

1. It will work with the AIM, SYM or KIM without modification. The program contains code to determine which microcomputer is being used and makes all necessary adjustments automatically. The program can be placed in EPROM and still be used on all three micros.
2. It interfaces directly to the AIM and SYM monitor via their provisions for OUTPUT and/or INPUT vectors, and it sets up these vectors automatically during initialization of the program.
3. It supports an ASCII keyboard so that a keyboard may be added to the AIM, SYM or KIM with full UPPER and lower case capabilities.
4. It works directly with AIM BASIC and SYM BASIC.
5. It supports the following control functions:

Carriage Return	CR	Position Cursor at start of next line
Home	↑H	Position Cursor at upper left corner
Up/Down/Left/Right	↑U ↑D ↑L ↑R	Move Cursor without altering screen contents
Scroll	↑S	Automatic and Manual Scroll
Upper Case Mode	↑A	Automatically convert alpha characters to upper case
Lower Case Mode	↑A	Permit lower case characters, even on SYM
Echo	↑F	Automatic Echo may be selected or suppressed
Parity/PCG Characters	↑P	Bit 80 may be permitted or suppressed
Auto Linefeed	↑Q	Linefeed following Carriage Return may be suppressed
Escape/Break	[↑B]	Return to AIM/SYM/KIM Monitor from Keyboard
Delete	[-]	Delete characters in Editor, BASIC, Monitor
Input from Display	↑Z	Read characters from Display instead of Keyboard
Erase	↑E	Erase Display from Cursor to End of Screen
Clear	↑X	Clear the entire Display

[SYM Control Code]

6. It automatically adjusts to 40 character TV mode or 80 character Monitor mode.
7. The program is totally position independent. It may be placed anywhere in memory [except pages zero and one, of course], may be placed in EPROM, may be moved from one of the ASK family micros to another without modification, and does not require any user programming [except for a short startup program on the KIM]. The user sets the A register to a specified value and starts the program at the video initialization address. The keyboard is separately initialized by executing the keyboard initialization routine.
8. Since the KIM does not have INPUT and OUTPUT vectors, a method of having user defined INPUT and OUTPUT locations initialized on the KIM is supported. It is very easy, for example, to use this software with the MICRO-ADE Assembler/Disassembler/Editor package without modification!

ASK VIDEO PLUS Loading Instructions

The ASK VIDEO PLUS tape contains four files recorded in the standard KIM cassette tape format. This format may be loaded by the AIM, SYM or KIM. The AIM or SYM owner can load the tape in KIM format once, and then save it in the higher speed format supported by his AIM or SYM. A KIM owner who has "Hypertape" can save it in this format.

SYNCS: The first file on the tape is 1024 SYNC characters. This may be used, with the suitable program provided with your AIM, SYM, or KIM to adjust your tape recorder to the optimal value for reading the remainder of the tape.

MEMORY TEST [ID 10]: The Memory Test is the same as that listed in the VIDEO PLUS Manual. It loads into 0000 through 00D8 and can be used to test RAM. Put the address of the first page to be tested into 0000; the address of the last page to be tested into 0001; start the program at 0002. If no errors are encountered, then the program will stop with the LED display containing the address following the highest address tested. Otherwise, it will stop on the address with the error. See the VIDEO PLUS Manual or UPDATE 1 for details.

ASK VIDEO PLUS [ID 20]: This loads into 4000 through 4546. This is the space normally allocated to the VIDEO PLUS Display RAM. Set the switch on your VIDEO PLUS to the 4000 setting before loading this program.

AIM: Set A408 to 5A for KIM format tape. Use the K device for input. Filename is 20.

SYM: Use LD1 to load KIM format tape. Program ID is 20.

KIM: Normal load with Program ID of 20. If you wish to force load it to some other address, set 17F5/17F6 to the desired address, cue the tape to this third tape file, set 17F9 to FF. If ID 20 is used, then the program will load into 4000.

The program may **NOT** be run at 4000! This is the display memory. It must be moved to wherever in memory you plan to normally run it. Since the code is totally position independent, where you put it depends on the configuration of your system. If you are not currently using the Programmable Character Generator RAM on the VIDEO PLUS, then this is a handy place. A natural place for the AIM would be to have the VIDEO PLUS set for 8000 [Display RAM] and the program at 9000 [Programmable Character Generator RAM]. A natural place for the SYM would be to have the VIDEO PLUS set for 6000 and the program at 7000. Since the KIM has so much open space, the VIDEO PLUS and program might be placed almost anywhere. The ASK VIDEO PLUS Software does not have to be located in the VIDEO PLUS memory. If it is located in the VIDEO PLUS memory, then the initialization process is a little simpler. If it is located somewhere else, then the user must provide an initialization table which will be described below.

BMOVE [30]: The KIM user can force load the ASK VIDEO PLUS program anywhere he wants using the KIM loader. The SYM user can move the program after loading it, by using the BMOVE command of the SYM Monitor. The AIM user needs some way to move the program. This BMOVE program loads into 0000. Locations 0000/0001 are set to the FROM address, 0002/0003 are set to the TO address, and 0004/0005 are set to the number of bytes to be moved. For example, to move the ASK program from 4000 to 5000, with the program 546 bytes long [4000 through 4545], the values would be:

0000 00, 0001 40, 0002 00, 0003 50, 0004 46, 0005 05.

The program starts at 0006. After running, the ASK program would now be located at 5000 through 5545. The BMOVE program is a useful utility and will work on the AIM, SYM, or KIM.

Once the program has been moved to its "final resting place", it should be saved on tape in your system's high speed format. The KIM can dump it using "Hypertape" [see MICRO #1, "Hypertape and Ultratape", pgs 13-16, or Best of MICRO Volume 1, pgs 8-11]. The SYM can use the Save 2 command. The AIM can use its normal dump, but must remember to first restore location A408 to C7 and then use T as the output device.

Initializing the ASK VIDEO PLUS Software

AIM: If the ASK program is located in VIDEO PLUS memory, in the PCG RAM at 5000, then the following steps will initialize the video as output device:

1. A = EA Make SETUP call Video Init.
2. * = 5500 Set Program Counter to start of SETUP.
3. G/ Execute SETUP and VIDEO Initialization

All output that would normally go to the LED display will now appear on the video monitor. **Caution:** Do not put the AIM into Single Step Mode. This will bomb the video program.

You can now use the AIM Monitor, Editor and BASIC with output going to the display. A note about the Editor: the maximum width of a line for the Editor is 60 characters. If you exceed this limit, the additional characters will be lost. They will appear on the screen as you type them, but will not be placed into the Editor buffer. So, be careful. You can change the screen parameters so that the line length is only 60 characters wide. See COLROW Subroutine.

If the ASK VIDEO PLUS program is NOT in the VIDEO PLUS memory space, then a slightly different procedure is required. Assume for this example that the program is at 2000 and the VIDEO PLUS is selected at 8000:

1. A = 00 Make SETUP return to Monitor.
2. * = 2500 Set Program Counter to start of SETUP.
3. G/ Execute SETUP.
4. A = 80 Set A to start of VIDEO PLUS Display RAM at 8000.
5. X = ED Low address of Initialization TABLE.
6. Y = 23 High address of Initialization TABLE.
7. * = 2067 Address of USER Entry to VIDEO Initialization.
8. G/ Execute USER VIDEO Initialization.

If the standard TABLE is not used, then X and Y must be set to point at an equivalent initialization table. See page 14 of the listing for the TABLE characteristics and values.

If you desire to use an external ASCII keyboard connected to the VIDEO PLUS, and assuming the ASK program is at 5000, the initialization procedure consists of:

1. * = 5400 Set Program Counter to Keyboard Initialization.
2. G/ Execute the Keyboard Initialization.

The ASCII keyboard is not setup as the USER Input device. It can not be used with the Monitor or Editor since they go directly to the AIM Keyboard or a TTY. The ASCII keyboard may be used with BASIC. Run BASIC using the normal 5 command. Set Memory Size as desired and Width will default to 60 characters. When BASIC starts, it is getting input from the AIM Keyboard. To switch to the ASCII Keyboard, location A412 must be changed to a "U" or hex 55. The following statement will accomplish this:

POKE 42002,85 Where 42002 = A412 hex and 85 = 55 hex.

Input will now come from the ASCII Keyboard. It will initially be in UPPER case. Use CTRL A to toggle between UPPER and lower case modes. Remember, BASIC commands must be in UPPER case. To return to the AIM Keyboard for input:

POKE 42002,13 Where 42002 = A412 hex and 13 = 0D or CR.

To restore the LED's as the output device, the following program may be used. This simply changes the output vector back to the LED service routine. A similar routine allows switching back to the video for output.

0200 A9 05	LDAIM \$05	LED SERVICE AT EF05	Set Output to LED's
0202 8D 06 A4	STA \$A406	OUTPUT VECTCR AT A406, A407	
0205 A9 EF	LDAIM \$EF		
0207 8D 07 A4	STA \$A407		
020A 00	BRK	RETURN TO MONITOR	
020B A9 9F	LDAIM \$9F	VIDEO SERVICE AT XX9F	Set Output to VIDEO
020C ED 06 A4	STA \$A406	LOW ADDRESS OF OUTTV	
0210 A9 51	LDAIM \$51	HIGH ADDRESS = PROGRAM START	
0212 8D 07 A4	STA \$A407	ADDRESS + 1	
0215 00	BRK	RETURN TO MONITOR	

SYM: If the ASK program is located in VIDEO PLUS memory, in the PCG RAM at 5000, then the following steps will initialize the video as output device [**BOLD** represents the user input, **ITALIC** represents the SYM output]:

1. **REG CR P → S →**
F → A EA CR Make SETUP call Video Initialization.
2. **GO 5500 CR** Execute SETUP and VIDEO Initialization

All output that would normally go to the LED display will now appear on the video monitor. You can now use the SYM Monitor, Editor and BASIC with output going to the display.

If the ASK VIDEO PLUS program is **NOT** in the VIDEO PLUS memory space, then a slightly different procedure is required. Assume for this example that the program is at 2000 and the VIDEO PLUS is selected at 6000:

1. **REG CR P → S →**
F → A 00 CR SETUP returns to Monitor, if A = 00.
2. **GO 2500 CR** Execute ASK SETUP.
3. **REG CR P → S →**
F → A 60 → Set A to start of VIDEO PLUS Display RAM at 6000.
4. **X ED →** Low address of Initialization TABLE.
5. **Y 23 CR** High address of Initialization TABLE.
6. **GO 2067 CR** Execute at USER Entry to VIDEO Initialization.

If the standard TABLE at 23ED is not used, then X and Y must be set to point at an equivalent initialization table. See page 14 of the listing for the TABLE characteristics and values.

If you desire to use an external ASCII keyboard connected to the VIDEO PLUS, and assuming the ASK program is at 5000, the initialization procedure consists of:

1. **GO 5400 CR** Execute the Keyboard Initialization.

The ASCII keyboard is now setup as the Input device. It can be used with the Monitor, Editor, or BASIC, since they all go through the Input and Output Vectors. Run BASIC by a **GO C000 CR** command. Set Memory Size as desired and Width will default to 60 characters. It will initially be in UPPER case. Use CTRL A to toggle between UPPER and lower case modes. Remember, BASIC commands must be in UPPER case.

To restore the LED's as the output device, the following command may be used. This simply changes the output vector back to the LED service routine. **SD 8900,A664 CR** where 8900 is the address of the standard display output routine, HDOUT, and A664 is the address of OUTVEC. A similar command allows switching back to the video for output. **SD 519F,A664 CR** where 519F is the entry to the video output service, assuming the program starts at 5000.

KIM: If the ASK program is located in VIDEO PLUS memory, in the PCG RAM at 5000, then the following steps will initialize the video as an output device, the keyboard as an input device, will set up a vector that can be used to test whether or not the keyboard has a character present, and will then permit the user to type to the display:

1. Enter the following program anywhere in free memory:

0200 49 EA	INIT	LDAIM \$EA	RUN SETUP AND VIDEO INIT
0202 20 00 55		JSR SETUP	ASSUME PROGRAM AT 5000
0205 20 00 54		JSR KBINIT	INIT KEYBOARD
0208 20 00 00	IN	JSR KBTEST	IS THERE ANY DATA PRESENT
020B 90 FB		BCC IN	WAIT FOR IT. THIS IS NOT REQUIRED
020C 20 00 00		JSR KBWAIT	GET DATA FROM KEYBOARD
0210 20 00 00		JSR OUTTV	OUTPUT IT
0213 4C 08 02		JMP IN	GET MORE

ACTUAL VALUES OF KBTEST, KBWAIT AND OUTTV
WILL BE FILLED IN BY INITIALIZATION.

2. In address 0000/0001 put the address of the Output Vector, in this example 0211. In address 0002/0003 put the address of the Keyboard Test Vector, in this example 0209. In address 0004/0005 put the address of the Keyboard Input Vector, in this example 020E.

3. Enter address 0200 and press GO. The display will initialize and clear. Whatever is typed will appear on the screen with all of the control functions working: up, down, erase, and so forth. If the program is stopped and the locations pointed to by 0000 through 0005 at initialization time are examined, it will be found that these location now contain the addresses of the ASK routines: 0209/020A have 7D/54, the address of KBTEST [547D]; 020E/020F have 8E/54 [548E], the address of KBWAIT; and 0211/0212 have 9F/51 [519F], the address of OUTTV. These values will of course change if the ASK Software is moved to other locations in memory.

The KIM Monitor does not have any provision for changing its basic input and output vectors. It always gets data from the hexpad or TTY and always sends data to the LEDs or TTY. There is, unfortunately, no way around this, but most available programs do support input and output through vectors which can be set to interact with the ASK VIDEO PLUS Software.

If you are planning to use ASK VIDEO PLUS with an existing program, then find where the I/O is vectored through, and put the address of the Output Vector in 0000/0001, the Keyboard Test Vector (if any) in 0002/0003, and the Keyboard Input Vector in 0004/0005. Run the following program and you should be in business. For example, MICRO-ADE has its Output Vector at 2EA1, its Input Vector at 2E9E, and does not have a Keyboard Test Vector. The initial vector pointers would therefore be set:

0000 A1, 0001 2E, 0002 FE, 0003 FF, 0004 9E, 0005 2E

Since there is no Keyboard Test Vector, its pointer was set to FFFE, which being a KIM ROM location can not be modified and will not be adversely affected by the attempt of the Keyboard Initialization to modify it.

If the ASK VIDEO PLUS program is NOT in the VIDEO PLUS memory space, then a slightly different procedure is required. Assume for this example that the program is at 2000 and the VIDEO PLUS is selected at 6000:

1. Enter the following program:

0200 A9 60	INIT	LDAIM \$60	RUN SETUP AND RETURN
0202 20 00 25		JSR SETUP	ASSUME PROGRAM AT 2000
0205 A9 60		LDAIM \$60	DISPLAY RAM PAGE ADDRESS
0207 A2 ED		LDXIM \$ED	LOW TABLE ADDRESS
0209 A0 23		LDYIM \$23	HIGH TABLE ADDRESS
020B 20 58 00		JSR TTABLE INIT VIDEO	
020E 20 00 54		JSR KBINIT INIT KEYBOARD	
0211 20 00 00	IN	JSR KBWAIT GET DATA FROM KEYBOARD	
0214 20 00 00		JSR OUTTV OUTPUT IT	
0217 4C 11 02		JMP IN	GET MORE

ACTUAL VALUES OF KBTEST, KBWAIT AND OUTTV
WILL BE FILLED IN BY INITIALIZATION.

2. Enter 0200 and GO.

If the standard TABLE at 23ED is not used, then X and Y must be set to point at an equivalent initialization table. See page 14 of the listing for the TABLE characteristics and values.

ASK VIDEO PLUS Program Notes

The following information is, in general, not required for using the ASK software, but is useful in understanding how it works. It is included to make the total package more useful. One note: all addresses are given as they are in the listing, that is, relative to zero. To find the actual address in a particular configuration, simply add the base address of where the program is residing to the address given. For example, the Initialization Table is listed at 03ED. If the ASK Software is at 5000, then the Table is at 53ED.

1. Initialization Table [03ED]: This TABLE contains the information that is required to initialize the ASK Software, in particular that required by the CRT Controller 6845. See the 6845 Data Sheet included with the VIDEO PLUS Manual for additional detail. The TABLE has the following values and functions:

Address	Hex	Dec	Function
03ED	7A	122.	Horizontal Total in Character Time
03EE	50	80.	Horizontal Characters Displayed
03EF	60	96.	Horizontal Sync Position
03F0	0A	10.	Horizontal Sync Width - a fudge factor!

Note: The Horizontal values are divided in half when operating in the TV mode. This is automatically done by the ASK Software and should be taken into account when setting up or modifying an Initialization Table.

03F1	13	19.	Vertical Total - 1 In Character Lines
03F2	1E	30.	Vertical Total Adjust - a fudge factor!
03F3	14	20.	Vertical Lines Displayed
03F4	14	20.	Vertical Sync Position

Note: The Vertical values are not changed for the TV mode.

03F5	00	0.	Scan Mode: Non-interlace.
03F6	0C	12.	Maximum Scan Line Address: 0 - 12 = 13 Scan Lines
03F7	4C	76.	Cursor Blink Rate [40] and Cursor Raster Start [0C]
03F8	0C	12.	Cursor Raster End
03F9	00	0.	Start Address High or Offset into Display Memory initially at zero
03FA	00	0.	Start Address Low
03FB	00	0.	Cursor Address High is initially zero
03FC	00	0.	Cursor Address Low is initially zero

2. Important Program Locations: There are several locations in the program that make interacting with it simple. All addresses are as given in the listing.

SETUP [0500]: This routine is used to establish where the ASK VIDEO PLUS Software is currently residing. It sets up a subroutine return [RTS] on page zero, does a subroutine call to this return [JSR], and then pulls the return address off the stack to determine where it is in memory. It then uses this information to calculate the starting address of the ASK Software which is the beginning of the JUMP processor. It puts a vector to the JUMP processor into 0178. If the ASK Software was located at 5000, then the following would be placed into memory: 0178 4C 00 50

This is a JMP to 5000, the start of the JUMP processor. Similarly, a JMP to the SUBR processor is placed into memory: 017B 4C 05 50. These two jump vectors are used whenever the resident ASK Software needs to make an internal JMP or JSR. SETUP now determines what it should do next as a function of the value that was in the A register initially. If A was 00, then a BRK is executed. If A was 60, then an RTS is executed. If A was EA, then SETUP transfers directly to the video initialization at TTABLE [0058].

Video Initialization [TTABLE 0058]: There are two ways to initialize the video. The first assumes that the TABLE of initialization values at 03ED is the correct one to use and that the ASK Software is resident somewhere on the VIDEO PLUS board, in RAM or ROM - it doesn't matter. If this is true, then the entry is at 0058. The pointers to the TABLE are corrected using the data in 0179/017A, and the beginning of the Display Memory RAM is calculated from the program address. If the above assumptions are not true, then entry must be made at **USER [0067]**. The A register must contain the Display RAM Page Number, e.g. 40 if the RAM is at 4000; X is the low address of an initialization table [ED if the standard table is to be used]; and Y is the high address of the initialization table [23 if the ASK Software is at 2000]. The initialization routine calculates the CRT Controller address; tests for up to 8 pages [2K] of Display RAM; determines whether the microcomputer is an AIM, SYM, or other [probably KIM]; checks the TV/Monitor jumper; and then initializes the CRT Controller. If the TV switch/jumper is set for TV, then the horizontal values are divided by 2, so that 80 character per line in the table becomes 40 character per line to the controller. A call is made to the COLROW subroutine which sets up the row and column limits and calculates the screen size. The output vectors for the AIM, SYM, or other [KIM] are now set to point to OUTTV, the ASK Software entry point for video output. The cursor is HOME'd and the screen cleared and control is returned to the user. An AIM or SYM make a BREAK to the Monitor. The KIM [or other] makes an RTS.

JRTN [0000] and SRTN [0005]: All internal JMP's or JSR's are shown in the listing as: JMP ADDR, NOP, NOP or JSR ADDR, NOP, NOP. This is not what is actually in memory. The code in memory for a JMP is actually: JSR 0178, ADDR LO, ADDR HI, where 0178 is the vector to the JUMP processor, and ADDR LO/ADDR HI are the low and high address of the ADDR (or whatever) location relative to the start of the ASK Software. The code for a JSR is identical except that the JSR goes to 017B. The JUMP and SUBR processors use the return pointer on the stack to retrieve the next two bytes of memory which are the relative offset of the desired address. These are added to the starting address of the ASK Software and a JMP is made to the correctly modified address. The only difference between the JUMP and SUBR processors is that the JUMP processor must correct the stack pointer to remove the unwanted JSR return. Examination of the **JRTN [0000]** and **SRTN [0005]** routine listings will provide additional details.

KBINIT [0400]: The video must be initialized before the keyboard. KBINIT first sets up the KBTEST and KBWAIT vectors, storing them in the appropriate vectors for the AIM, SYM or KIM. The VIA 6522 is then initialized to permit the input of data through the I/O port on the VIDEO PLUS. An AIM or SYM return to the Monitor via a BRK; the KIM returns via an RTS.

KBTEST [047D]: When KBTEST is called by the SYM or KIM (there is no provision for a keyboard test on the AIM) it tests the VIA to determine if any data is present. If there is data present, then the carry bit is set. If there is no data present, then the carry bit is cleared. By testing the carry bit upon return from a KBTEST call, the calling program can determine whether or not there is data present on the keyboard.

KBWAIT [408E]: When KBWAIT is called it first determines whether the call was from an AIM. If so, it must then test the carry bit to determine if this is an initialization call or a data call. If the carry pit is clear, then it is an initialization call. Since the initialization has already taken place, no further action is required and a return is made. Otherwise, and always for a SYM or KIM, the keyboard is tested for data. If no data is present, then the test is repeated until data is present. When data is present, it is read in via the VIA. A flag is tested to see if only UPPER case is permitted, or if lower case is permitted as well. If only UPPER case is permitted, the lower case alphabetic characters, "a" to "z" are converted to upper case "A" to "Z". An AIM or KIM then test for the Echo Flag. If it is set, they echo the character via OUTTV. If it is not set, they return to the calling routine with the character in the A register. A SYM first tests its own echo flag in TECCHO. If its echo flag is set, or if the ASK echo flag is set, then it echos. Otherwise it modifies the return to the SYM by adding 0C to the return address on the stack to skip around the automatic UPPER case conversion routine in the SYM.

OUTTV [019F]: This is the entry point to output a character, or service a control code, to the video. The A, X, and Y registers are saved and a test is made to insure that the cursor is within the screen window. If not, it is restored to the home position. A series of tests are now performed to determine if the character supplied in the A register is a command character. If it is a command character for the microcomputer being run, then it is serviced. If it is not, then it is displayed. All registers are restored before a final return is made. The calling program should **not** try to use the subroutines directly, since the final path always restores the registers and removes one level of stack. It is much easier for the calling program to put the command character in the A register and call OUTTV.

COLROW [0139]: One exception to the above rule is the COLROW subroutine. This routine permits the number of columns and rows on the screen to be easily changed without affecting the various other initialization parameters. The A register contains the column limit and the X register the row limit. COLROW sets these limits and recalculates the screen window.

4. Control Z Feature: A command is provided which permits data to be read from the screen by BASIC, Editors, the Monitor, etcetera. This feature only works if input is via the ASCII keyboard through the ASK Keyboard service. The function is simple: whenever a tZ is encountered on input from the keyboard, the character at the current cursor position is read, the cursor is incremented to the next position, and the character which was on the screen is passed back to the calling routine. This feature makes it easy to edit lines in BASIC or any other program, by simply moving the cursor to the desired position, "reading" characters from the screen with the tZ, typing in new characters wherever desired, and so forth. Try it, you'll like it!

A Final Word

This is the first release of the ASK VIDEO PLUS Software package. While every effort has been made to make it "perfect", I am sure that it contains some mistakes. The program should work without too much difficulty, but may have some bugs. If you find any serious bugs in the program or the documentation, or if you have any suggestions to improve the program or documentation, please be sure that all such input would be appreciated. Send your comments to:

Robert M. Tripp, The COMPUTERIST, Inc., P.O. Box 3, So. Chelmsford, MA 01824.
If a serious problem or misunderstanding arises, you can call me at 617/256-3649.

0010:	AIM/SYM/KIM VIDEO PLUS	0570: 0546	COMIN *	\$E1A1	BREAK ENTRY POINT
0020:		0580: 0546	DSPVEC *	\$EF05	DISPLAY VECTOR VALUE
0030:	21 DECEMBER 1979	0590:			
0040:	ROBERT M. TRIPP	0600:			
0050:		0610:			
0060:	MODIFIED 11 JANUARY 1980	0620: 0546	ACCESS *	\$8B86	
0070:	BASED ON ROCKWELL INTERNATIONAL APPLICATION NOTE	0630: 0546	NACCES *	\$8B9C	NOT ACCESS
0080:		0640: 0546	TECHO *	\$A653	ECHO FLAG
0090:	COPYRIGHT (C) 1979 BY:	0650: 0546	OUTVEC *	\$A663	OUTPUT VECTOR
0100:	THE COMPUTERIST, INC.	0660: 0546	INVEC *	\$A660	INPUT VECTOR
0110:	P.O. BOX 3	0670: 0546	INSVEC *	\$A666	TEST INPUT VECTOR
0120:	SC. CHELMSFORD, MA 01824	0680:			
0130:	617/256-3649	0690:			
0140:		0700:			
0150:		0710: 0546	KOUT *	\$0000	ADDRESS OF KIM OUTPUT VECTOR
0160:	PAGE ZERO EQUATES	0720: 0546	KTST *	\$0002	ADDRESS OF KIM KEYBOARD TEST VECTOR
0170:		0730: 0546	KIN *	\$0004	ADDRESS OF KIM INPUT VECTOR
0180: 0546	CURSOR * \$00F0	0740:			
0190: 0546	CRTREG * \$00F2	CRT CONTROLLER/VIA POINTER	0750: 0000	ORG \$0000	RELOCATABLE
0200: 0546	SCRLOW * \$00F4	SCREEN POINTER	0760:		
0210: 0546	LRT * \$00F6		0770:		JUMP SUBROUTINE TO FIX RELOCATEABLE JUMPS
0220: 0546	HRT * \$00F7		0780:		
0230:			0790:		
0240:	PAGE ONE EQUATES		0800:		JSR JUMP (OFFSET TO REAL JUMP LOCATION)
0250:			0810:		
0260: 0546	CURPRM * \$0170	CURSOR POSITION STUFF	0820: 0000 08	JRTN PHP	SAVE STATUS
0270: 0546	CURPO * \$0171		0830: 0001 EE 7E 01	INC JFLAG	SET JUMP FLAG
0280: 0546	COLMAX * \$0172	COLUMN MAXIMUM	0840: 0004 28	PLP	RESTORE STATUS
0290: 0546	RAMPAG * \$0173	START OF DISPLAY RAM	0850:		
0300: 0546	RAMEND * \$0174	END OF DISPLAY RAM	0860:		SUBR SUBROUTINE TO FIX RELOCATABLE SUBRS
0310: 0546	ASK * \$0175	AIM/SYM/KIM FLAG	0870:		
0320: 0546	LSUB * \$0176		0880:		
0330: 0546	HSUB * \$0177		0890:		JSR SUBR (OFFSET TO REAL SUBR LOCATION)
0340: 0546	JUMP * \$0178		0900:		
0350: 0546	SUBR * \$017B		0910: 0005 08	SRTN PHP	
0360: 0546	JFLAG * \$017E		0920: 0006 48	PHA	SAVE REGISTERS
0370: 0546	XTEMP * \$017F	TEMPORARY STORAGE	0930: 0007 8A	TXA	
0380: 0546	YTEMP * \$0180	TEMPORARY STORAGE	0940: 0008 48	PHA	
0390: 0546	LCHAR * \$0181	LAST OUTPUT CHARACTER	0950: 0009 98	TYA	
0400:			0960: 000A 48	PHA	
0410:	ASK FLAGS		0970: 000B BA	TSX	GET STACK POINTER
0420:			0980: 000C 18	CLC	
0430:	OX = AIM		0990: 000D BD 05 01	LDAX \$0105	GET LOW RETURN ADDRESS - 1
0440:	4X = KIM		1000: 0010 85 F6	STA LRT	
0450:	6X = SYM		1010: 0012 BD 06 01	LDAX \$0106	GET HIGH RETURN ADDRESS
0460:	X1 = UPPER CASE (0)/LOWER CASE (1)		1020: 0015 85 F7	STA HRT	
0470:	X2 = STRIP BIT 80 (0)/PERMIT BIT 80 (1)		1030:		
0480:	X4 = FULL DUPLEX (0)/HALF DUPLEX (1)		1040: 0017 A0 01	LDYIM \$01	PICKUP LOW OFFSET
0490:	X8 = NOT AUTO CRLF (0)/AUTO CRLF (1)		1050: 0019 B1 F6	LDAIY LRT	
0500:			1060: 001B 6D 79 01	ADC JUMP	+01 LOW OFFSET
0510:	AIM EQUATES		1070: 001E 8D 76 01	STA LSUB	
0520:			1080: 0021 C8	INY	PICKUP HIGH OFFSET
0530: 0546	UTN * \$0108	USER INPUT VECTOR	1090: 0022 B1 F6	LDAIY LRT	
0540: 0546	CURPOZ * \$A415		1100: 0024 6D 7A 01	ADC JUMP	+02 HIGH OFFSET
0550: 0546	DTLINK * \$A406	DISPLAY LTKAGE	1110: 0027 8D 77 01	STA HSUB	
0560: 0546	DTBUFF * \$A436	DISPLAY BUFFER	1120:		

1130: 002A 18	CLC		0270: 0067 8D 73 01	USER	STA	RAMPAG	SAVE RAM DISPLAY START
1140: 002B A5 F6	LDA LRT	FIX FINAL SUBROUTINE RETURN	0280: 006A 86 F0		STX	CURSOR SET TABLE POINTER LOW	
1150: 002D 69 02	ADCIM \$02	PAST PARAMETERS	0290: 006C 84 F1		STY	CURSCR +01 AND HIGH IN POINTER	
1160: 002F 9D 05 01	STAX \$0105	PUT BACK ON STACK	0300: 006E 85 F5		STA	SCRLOW +01 SAVE RAM START	
1170: 0032 A5 F7	LDA HRT	FIX HIGH BYTE	0310: 0070 8D 74 01		STA	RAMEND FOR RAM END TEST	
1180: 0034 69 00	ADCIM \$00	IN CASE OF CARRY	0320: 0073 09 18		CRAIM \$18	CALC. CRT ADDRESS	
1190: 0036 9D 06 01	STAX \$0106		0330: 0075 85 F3		STA	CRTREG +01	
1200:			0340: 0077 A2 00		LDXIM \$00	FIX LOW ADDRESSES	
1210: 0039 68	PLA	RESTORE REGISTERS	0350: 0079 86 F4		STX	SCRLCW	
1220: 003A A8	TAY		0360: 007B 86 F2		STX	CRTREG	
1230: 003B 68	PLA		0370:				
1240: 003C AA	TAX		0380: 007D A0 08		LDYIM \$08	TEST RAM END	
1250: 003D 68	PLA		0390: 007F A9 00	TLOOP	LDAIM \$00		
1260: 003E CE 7E 01	DEC JFLAG	TEST JUMP/SUBR	0400: 0081 81 F4		STAIX	SCRLCW WRITE 00	
1270: 0041 F0 05	BEQ JDCNE	JUMP	0410: 0083 A1 F4		LDAIX	SCRLCW READ IT BACK	
1280: 0043 EE 7E 01	INC JFLAG	RESTORE FLAG	0420: 0085 D0 06		BNE	TDONE ANYTHING ELSE (FF?)	
1290: 0046 F0 0C	BEQ JSOUT	ALWAYS	0430: 0087 EE 74 01		INC	RAMEND BUMP RAM END	
1300:			0440: 008A 88		DEY		
1310: 0048 85 F6	JDCNE STA	LRT MUST CLEANUP STACK	0450: 008B D0 F2		BNE	TLOOP TRY FOR EIGHT PAGES	
1320: 004A 68	PLA		0460:				
1330: 004B 85 F7	STA HRT	STATUS	0470: 008D A9 40	TDONE	LDAIM \$40	SETUP AIM/SYM/KIM FLAG	
1340: 004D 68	PLA	LOW	0480: 008F AE FD FF		LDX \$FFFF	TEST ROM RESET ADDRESS	
1350: 004E 68	PLA	HIGH	0490: 0092 E0 8B		CPXIM \$8B	SYM ?	
1360: 004F A5 F7	LDA HRT	STATUS	0500: 0094 D0 05		BNE	SETAK NO.	
1370: 0051 48	PHA		0510: 0096 20 86 8B		JSR	ACCESS SYM	
1380: 0052 A5 F6	LDA LRT	A REG	0520: 0099 A9 80		LDAIM \$80	SYM FLAG = 80	
1390: 0054 28	JSOUT PLP	RESTORE STATUS	0530: 009B E0 30	SETAK	CPXIM \$E0	AIM ?	
1400: 0055 6C 76 01	JMI LSUB		0540: 009D D0 02		BNE	SETASK NO	
1410:			0550: 009F A9 00		LDAIM \$00	AIM FLAG = 00	
1420:			0560:				
ID=11			0570: 00A1 8D 75 01		SETASK STA	ASK AIM=00/SYM=80/KIM=40	
0010:			0580: 00A4 B8		CLV		
0020:		INITIALIZE THE VIDEO OUTPUT ROUTINES	0590: 00A5 A0 04		LDYIM \$04	TEST TV OR MONITOR MODE	
0030:			0600: 00A7 B1 F2		LDAIY	CRTREG READ ONBOARD JUMPER	
0040:		THE SETUP CALL WILL COME HERE AUTOMATICALLY IF	0610: 00A9 4A		LSRA	SHIFT TO TEST	
0050:		THE A REGISTER IS SET TO \$EA BEFORE THE CALL TO	0620: 00AA 4A		LSRA	BIT 2 = 1 FOR TV MODE	
0060:		SETUP.	0630: 00AB 90 04		BCC	INIT 0 FOR MONITOR	
0070:			0640: 00AD A9 7F		LDAIM \$7F	TV SO SET OVERFLOW FOR	
0080:		ENTRY POINT IF SOFTWARE IS IN VP ROM	0650: 00AF 69 02		ADCIM \$02	TESTING BELOW	
0090:		OR IN PCG RAM ON VIDEO PLUS	0660:				
0100:			0670: 00B1 A0 00	INIT	LDYIM \$00	SET INDEXES	
0110: 0058 A9 ED	TTABLE LDAIM TABLE	TABLE RELATIVE TO JRTN	0680: 00B3 A2 00		LDXIM \$00		
0120: 005A 18	CLC		0690: 00B5 98	INITA	TYA	NEXT REGISTER IN CRT	
0130: 005B 6C 79 01	ADC JUMP	+01	0700: 00B6 81 F2		STAIX	CRTREG	
0140: 005E AA	TAX		0710: 00B8 E6 F2		INC	CRTREG POINT TO REAL REGISTER	
0150: 005F A9 03	LDAIM TABLE	/	0720: 00BA B1 F0		LDAIY	CURSCR TABLE VALUE	
0160: 0061 6C 7A 01	ADC JUMP	+02	0730: 00BC 50 01		BVC	INITB TEST TV/MONITOR	
0170: 0064 A8	TAY		0740: 00BE 4A		LSRA	TV SO DIVIDE HORIZONTAL VLAUES	
0180: 0065 29 30	ANDIM \$E0	CALC. RAM DISPLAY START	0750: 00BF 81 F2	INITB	STAIX	CRTREG STORE VALUE	
0190:			0760: 00C1 C6 F2		DEC	CRTREG POINT TO DUMMY REGISTER	
0200:		ENTRY POINT IF SOFTWARE IS NOT IN VIDEO PLUS	0770: 00C3 C0 01		CPYIM \$01	HORZ CHAR PER LINE?	
0210:		OR IF USER WANTS TO USE ANOTHER TABLE	0780: 00C5 D0 01		BNE	INITC	
0220:			0790: 00C7 48		PHA	SAVE COLMAX	
0230:		A = DISPLAY RAM PAGE NUMBER	0800: 00C8 C8	INITC	INY	BUMP INDEX	
0240:		X = TABLE ADDRESS LOW	0810: 00C9 C0 04		CPYIM \$04	TEST DCNE WITH HORZ.	
0250:		Y = TABLE ADDRESS HIGH	0820: 00CB 30 E8		BMI	INITA NC, MAINTAIN TV TEST	
0260:							

0830: 00CC3 B6 CLV YES, CLRAY SCRLOCW
 0840: 00CC3 C0 10 INIT3 COPYIN \$10 TEST END OF TABLE
 0850: 00DD2 D0 33 BN3 INITA NO, KEEP GOING
 0860: 00DD2 A0 06 LDYIM \$06 LDAYI CURRSR PICK UP ROW MAXIMUM
 0880: 00DD4 B1 F0 TAX PUT IN X FOR COLOR PROCESSING
 0890: 00D27 68 PLA GET COLOR MAX FOR COLOR SUBROUTINE
 0900: 00D28 20 39 01 JSR SUBROUTINE CALL
 0910: 00D28 20 39 01 JSR COLOR SET COL/ROW AND CALCULATES
 0920: 00D28 20 39 01 NCP END OF SCREEN
 0930: 00DBB 3A NCP END OF SCREEN
 0940: 00DC E4 NCP RETURN TO MONITOR
 0950:
 0960: SET UP TRANSFER VECTORS FROM HOST
 0970: TO VIDEO PLUS.
 0980:
 0990: 00D28 20 39 01 PLA GET COLOR MAX FOR COLOR SUBROUTINE
 1000: 00D28 6D 79 01 LDATM GUTTY / PAGE
 1010: 0010: COLUMN/ROW SET SUBROUTINE
 1020: 0033 AA TAX THIS MAY BE CALLED BY THE INITIALIZATION ROUTINES.
 1030: 0034 99 01 ADC JUMP +01 TO SETUP TRANSFER VECTORS
 1040: 00E6 6D 7A 01 LDATM GUTTY / PAGE
 1050: 00E6 2C 75 01 BIT ASK AIM/SYM/KIM ?
 1060: 00E6 70 0A BVS INITK KIM
 1070: 00E6 10 13 BVS INITK KIM
 1080: 00E6 65 64 46 STX OUTVEC +01 AIM
 1090: 00E6 3D 65 A6 STA OUTVEC +02 AIM
 1100: 00F6 30 11 BMI INITF ALWAYS
 1110: 0120: LDYIM \$01 KIM INIT. STORES
 1120: 00F8 AD 01 INITK LDYIM \$01 KIM INIT. STORES
 1130: 00FA 91 00 STAY KOUT VECTORS VIA POINTERS
 1140: 0140: 0130: COLUMN/ROW SET SUBROUTINE
 1150: 0150: 0139 85 54 STA SCRLOCW SETUP SCRLOCW FOR SNDCP
 1160: 00FF3 91 00 STAY KOUT CLR OVERFLOW SET BY BIT ASK
 1170: 0100 00 CLV CLR OVERFLOW SET BY BIT ASK
 1180: 0101 50 06 BVC INITF ALWAYS
 1190: 0190: 0147 81 F2 STAIX CTRREG REGISTER
 1200: 0103 85 06 44 INITE STX DILINK AIM TRANSFER VECTORS
 1210: 0106 83 07 A4 STA DILINK +01
 1220: 0210: 0148 AD 72 01 LDAYI SCRLOCW
 1230: 0109 20 0A 03 INITF JSR HOMEQ HOME CURSCR
 1240: 0230: 0150 06 F2 STAIX CTRREG
 1250: 010C 3A NOP
 1260: 0110 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 1270: 0270: 0158 AD 7F 01 LDAYI SCRLOCW
 1280: 0280: 0158 81 F2 STAIX CTRREG
 1290: 0290: 0159 61 F2 STAIX CTRREG
 1300: 0300: 0159 66 F2 DEG CTRREG
 1310: 0310: LDAYI SCRLOCW
 1320: 0320: LDAYI SCRLOCW
 1330: 0330: 015F CE 7F 01 SNDCP DEC XTAMP ROW CENTER
 1340: 0340: 0162 FO 03 BEQ FINIS RETURN
 1350: 0350: 0164 18 CLC GET READY TO ADD
 1360: 0360: 0165 AD 72 01 LDAYI SCRLOCW
 1370: 0370: 0168 65 F4 ADC SCRLOCW
 1380: 0380: 016A 65 F4 STA SCRLOCW
 1390: 0390: 0163 36 55 INC SCRLOCW
 1400: 0400: 0170 10 BD BPL SNDLCP ALWAYS BRANCH
 1410: 0410: 0172 10 BD BPL SNDLCP +01 ADD IN CARRY
 1420: 0420: 0174 10 FB BPL CLR
 1430: 0430: 0176 29 0F ANDIM \$0F
 1440: 0440: 0178 85 F5 STA SCRLOCW +01
 1450: 0450: 017C 2C 75 01 BIT ASK AIM/SYM/KIM ?
 1460: 0460: 017F 70 06 BVS FINIS KIM
 1470: 0470: 0131 10 03 BPL FINI AIM
 1480: 0480: 0133 20 9C 8B JSR NACCS STM - TURN OFF ACCESS
 1490: 0490: 0136 00 FINI BRK RETURN TO KIM
 1500:
 1510: 0510: 0137 88 FINIS CLV RETURN TO KIM
 1520: 0520: 0138 60 FINIS RIS
 1530:
 1540: 0540: 0137 88 FINIS CLV
 1550: 0550: 0040: 0040: JSR COLOR
 1560: 0560: 0060: 0060: A = COLUMN MAXIMUM
 1570: 0570: 0070: X = ROW MAXIMUM
 1580: 0580: 0080: 0080: LDATM \$01
 1590: 0590: 0090: 0090: LDATM \$01
 1600: 0600: 0110: 0110: LDATM \$01
 1610: 0610: 0141 42 00 LDATM \$00
 1620: 0620: 0143 86 F5 LDATM \$00 UPDATE CRT CONTROLLE
 1630: 0630: 0144 2D 00 LDATM \$00 SCROLW SETUP SCRLOCW FOR SNDCP
 1640: 0640: 0145 86 F5 LDATM \$01 SCROLW +01 SCROLW FOR SNDCP
 1650: 0650: 0154 81 F2 STAIX CTRREG
 1660: 0660: 0156 36 F2 STAIX CTRREG
 1670: 0670: 0158 AD 7F 01 LDAYI SCRLOCW
 1680: 0680: 0158 81 F2 STAIX CTRREG
 1690: 0690: 0147 81 F2 STAIX CTRREG REGISTER
 1700: 0700: 0148 AD 72 01 LDAYI SCRLOCW
 1710: 0710: 0145 49 01 LDATM \$01 HCR. DISPLAY
 1720: 0720: 0145 86 F5 LDATM \$01 SCROLW +01 SCROLW FOR SNDCP
 1730: 0730: 0146 2D 00 LDATM \$00 UPDATE CRT CONTROLLE
 1740: 0740: 0147 81 F2 STAIX CTRREG
 1750: 0750: 0148 AD 72 01 LDAYI SCRLOCW
 1760: 0760: 0149 36 F2 STAIX CTRREG
 1770: 0770: 0149 86 F5 LDATM \$00 SCROLW SETUP SCRLOCW FOR SNDCP
 1780: 0780: 0149 86 F5 LDATM \$01 SCROLW SETUP SCRLOCW FOR SNDCP
 1790: 0790: 0149 81 F2 STAIX CTRREG
 1800: 0800: 0149 86 F5 LDATM \$01 SCROLW SETUP SCRLOCW FOR SNDCP
 1810: 0810: 0149 81 F2 STAIX CTRREG
 1820: 0820: 0149 86 F5 LDATM \$01 SCROLW SETUP SCRLOCW FOR SNDCP
 1830: 0830: 0149 81 F2 STAIX CTRREG
 1840: 0840: 0149 86 F5 LDATM \$01 SCROLW SETUP SCRLOCW FOR SNDCP
 1850: 0850: 0149 81 F2 STAIX CTRREG
 1860: 0860: 0149 86 F5 LDATM \$01 SCROLW SETUP SCRLOCW FOR SNDCP
 1870: 0870: 0149 81 F2 STAIX CTRREG
 1880: 0880: 0149 86 F5 LDATM \$01 SCROLW SETUP SCRLOCW FOR SNDCP
 1890: 0890: 0149 81 F2 STAIX CTRREG
 1900: 0900: 0149 86 F5 LDATM \$01 SCROLW SETUP SCRLOCW FOR SNDCP
 1910: 0910: 0149 81 F2 STAIX CTRREG
 1920: 0920: 0149 86 F5 LDATM \$01 SCROLW SETUP SCRLOCW FOR SNDCP
 1930: 0930: 0149 81 F2 STAIX CTRREG
 1940: 0940: 0149 86 F5 LDATM \$01 SCROLW SETUP SCRLOCW FOR SNDCP
 1950: 0950: 0149 81 F2 STAIX CTRREG
 1960: 0960: 0149 86 F5 LDATM \$01 SCROLW SETUP SCRLOCW FOR SNDCP
 1970: 0970: 0149 81 F2 STAIX CTRREG
 1980: 0980: 0149 86 F5 LDATM \$01 SCROLW SETUP SCRLOCW FOR SNDCP
 1990: 0990: 0149 81 F2 STAIX CTRREG
 2000: 0003 3A TAX THIS MAY BE CALLED BY THE INITIALIZATION ROUTINES.
 2010: 0003 6D 79 01 ADC JUMP +01 TO SETUP TRANSFER VECTORS
 2020: 0020: 0020: COLUMN/ROW SET SUBROUTINE
 2030: 0033 AA TAX IT IS CALLED BY THE INITIALIZATION ROUTINES.
 2040: 0040: 0040: LDATM GUTTY / PAGE
 2050: 0050: 0050: ADC JUMP +02
 2060: 0060: 0060: BPL INIT3 AIM
 2070: 0070: 0070: BVS INITK KIM
 2080: 0080: 0080: 0080: LDATM GUTTY / PAGE
 2090: 0090: 0090: 0090: LDATM GUTTY / PAGE
 2100: 0098 AD 01 INITK LDYIM \$01 KIM INIT. STORES
 2110: 0110: LDYIM \$01 KIM INIT. STORES
 2120: 0120: LDYIM \$01 KIM INIT. STORES
 2130: 0130: LDYIM \$01 KIM INIT. STORES
 2140: 0140: LDYIM \$01 KIM INIT. STORES
 2150: 0150: LDYIM \$01 KIM INIT. STORES
 2160: 0160: LDYIM \$01 KIM INIT. STORES
 2170: 0170: LDYIM \$01 KIM INIT. STORES
 2180: 0180: LDYIM \$01 KIM INIT. STORES
 2190: 0190: LDYIM \$01 KIM INIT. STORES
 2200: 0199 20 0A 03 INITF JSR HOMEQ HOME CURSCR
 2210: 0200: 0200: LDYIM \$01 KIM INIT. STORES
 2220: 0210: 0210: LDYIM \$01 KIM INIT. STORES
 2230: 0220: 0220: LDYIM \$01 KIM INIT. STORES
 2240: 0230: 0230: LDYIM \$01 KIM INIT. STORES
 2250: 0240: 0240: LDYIM \$01 KIM INIT. STORES
 2260: 0250: 0250: LDYIM \$01 KIM INIT. STORES
 2270: 0260: 0260: LDYIM \$01 KIM INIT. STORES
 2280: 0270: 0270: LDYIM \$01 KIM INIT. STORES
 2290: 0280: 0280: LDYIM \$01 KIM INIT. STORES
 2300: 0290: 0290: LDYIM \$01 KIM INIT. STORES
 2310: 0300: 0300: LDYIM \$01 KIM INIT. STORES
 2320: 0310: 0310: LDYIM \$01 KIM INIT. STORES
 2330: 0320: 0320: LDYIM \$01 KIM INIT. STORES
 2340: 0330: 0330: LDYIM \$01 KIM INIT. STORES
 2350: 0340: 0340: LDYIM \$01 KIM INIT. STORES
 2360: 0350: 0350: LDYIM \$01 KIM INIT. STORES
 2370: 0360: 0360: LDYIM \$01 KIM INIT. STORES
 2380: 0370: 0370: LDYIM \$01 KIM INIT. STORES
 2390: 0380: 0380: LDYIM \$01 KIM INIT. STORES
 2400: 0390: 0390: LDYIM \$01 KIM INIT. STORES
 2410: 0400: 0400: LDYIM \$01 KIM INIT. STORES
 2420: 0410: 0410: LDYIM \$01 KIM INIT. STORES
 2430: 0420: 0420: LDYIM \$01 KIM INIT. STORES
 2440: 0430: 0430: LDYIM \$01 KIM INIT. STORES
 2450: 0440: 0440: LDYIM \$01 KIM INIT. STORES
 2460: 0450: 0450: LDYIM \$01 KIM INIT. STORES
 2470: 0460: 0460: LDYIM \$01 KIM INIT. STORES
 2480: 0470: 0470: LDYIM \$01 KIM INIT. STORES
 2490: 0480: 0480: LDYIM \$01 KIM INIT. STORES
 2500: 0490: 0490: LDYIM \$01 KIM INIT. STORES
 2510: 0500: 0500: LDYIM \$01 KIM INIT. STORES
 2520: 0510: 0510: LDYIM \$01 KIM INIT. STORES
 2530: 0520: 0520: LDYIM \$01 KIM INIT. STORES
 2540: 0530: 0530: LDYIM \$01 KIM INIT. STORES
 2550: 0540: 0540: LDYIM \$01 KIM INIT. STORES
 2560: 0550: 0550: LDYIM \$01 KIM INIT. STORES
 2570: 0560: 0560: LDYIM \$01 KIM INIT. STORES
 2580: 0570: 0570: LDYIM \$01 KIM INIT. STORES
 2590: 0580: 0580: LDYIM \$01 KIM INIT. STORES
 2600: 0590: 0590: LDYIM \$01 KIM INIT. STORES
 2610: 0600: 0600: LDYIM \$01 KIM INIT. STORES
 2620: 0610: 0610: LDYIM \$01 KIM INIT. STORES
 2630: 0620: 0620: LDYIM \$01 KIM INIT. STORES
 2640: 0630: 0630: LDYIM \$01 KIM INIT. STORES
 2650: 0640: 0640: LDYIM \$01 KIM INIT. STORES
 2660: 0650: 0650: LDYIM \$01 KIM INIT. STORES
 2670: 0660: 0660: LDYIM \$01 KIM INIT. STORES
 2680: 0670: 0670: LDYIM \$01 KIM INIT. STORES
 2690: 0680: 0680: LDYIM \$01 KIM INIT. STORES
 2700: 0690: 0690: LDYIM \$01 KIM INIT. STORES
 2710: 0700: 0700: LDYIM \$01 KIM INIT. STORES
 2720: 0710: 0710: LDYIM \$01 KIM INIT. STORES
 2730: 0720: 0720: LDYIM \$01 KIM INIT. STORES
 2740: 0730: 0730: LDYIM \$01 KIM INIT. STORES
 2750: 0740: 0740: LDYIM \$01 KIM INIT. STORES
 2760: 0750: 0750: LDYIM \$01 KIM INIT. STORES
 2770: 0760: 0760: LDYIM \$01 KIM INIT. STORES
 2780: 0770: 0770: LDYIM \$01 KIM INIT. STORES
 2790: 0780: 0780: LDYIM \$01 KIM INIT. STORES
 2800: 0790: 0790: LDYIM \$01 KIM INIT. STORES
 2810: 0800: 0800: LDYIM \$01 KIM INIT. STORES
 2820: 0810: 0810: LDYIM \$01 KIM INIT. STORES
 2830: 0820: 0820: LDYIM \$01 KIM INIT. STORES
 2840: 0830: 0830: LDYIM \$01 KIM INIT. STORES
 2850: 0840: 0840: LDYIM \$01 KIM INIT. STORES
 2860: 0850: 0850: LDYIM \$01 KIM INIT. STORES
 2870: 0860: 0860: LDYIM \$01 KIM INIT. STORES
 2880: 0870: 0870: LDYIM \$01 KIM INIT. STORES
 2890: 0880: 0880: LDYIM \$01 KIM INIT. STORES
 2900: 0890: 0890: LDYIM \$01 KIM INIT. STORES
 2910: 0900: 0900: LDYIM \$01 KIM INIT. STORES
 2920: 0910: 0910: LDYIM \$01 KIM INIT. STORES
 2930: 0920: 0920: LDYIM \$01 KIM INIT. STORES
 2940: 0930: 0930: LDYIM \$01 KIM INIT. STORES
 2950: 0940: 0940: LDYIM \$01 KIM INIT. STORES
 2960: 0950: 0950: LDYIM \$01 KIM INIT. STORES
 2970: 0960: 0960: LDYIM \$01 KIM INIT. STORES
 2980: 0970: 0970: LDYIM \$01 KIM INIT. STORES
 2990: 0980: 0980: LDYIM \$01 KIM INIT. STORES
 3000: 0990: 0990: LDYIM \$01 KIM INIT. STORES
 3010: 0003 3A LDYIM \$01 KIM INIT. STORES
 3020: 0004 B1 F0 LDYIM \$01 KIM INIT. STORES
 3030: 00D6 AA LDYIM \$01 KIM INIT. STORES
 3040: 00E6 6D 7A 01 LDYIM \$01 KIM INIT. STORES
 3050: 00E6 2C 75 01 LDYIM \$01 KIM INIT. STORES
 3060: 00E6 70 0A LDYIM \$01 KIM INIT. STORES
 3070: 00E6 10 13 LDYIM \$01 KIM INIT. STORES
 3080: 00E6 65 64 46 LDYIM \$01 KIM INIT. STORES
 3090: 00F6 30 11 LDYIM \$01 KIM INIT. STORES
 3100: 0100 00 LDYIM \$01 KIM INIT. STORES
 3110: 0110 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3120: 0120 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3130: 0130 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3140: 0140 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3150: 0150 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3160: 0160 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3170: 0170 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3180: 0180 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3190: 0190 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3200: 0200 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3210: 0210 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3220: 0220 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3230: 0230 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3240: 0240 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3250: 0250 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3260: 0260 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3270: 0270 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3280: 0280 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3290: 0290 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3300: 0300 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3310: 0310 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3320: 0320 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3330: 0330 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3340: 0340 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3350: 0350 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3360: 0360 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3370: 0370 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3380: 0380 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3390: 0390 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3400: 0400 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3410: 0410 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3420: 0420 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3430: 0430 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3440: 0440 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3450: 0450 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3460: 0460 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3470: 0470 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3480: 0480 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3490: 0490 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3500: 0500 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3510: 0510 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3520: 0520 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3530: 0530 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3540: 0540 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3550: 0550 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3560: 0560 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3570: 0570 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3580: 0580 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3590: 0590 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3600: 0600 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3610: 0610 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3620: 0620 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3630: 0630 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3640: 0640 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3650: 0650 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3660: 0660 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3670: 0670 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3680: 0680 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3690: 0690 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3700: 0700 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3710: 0710 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3720: 0720 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3730: 0730 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3740: 0740 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3750: 0750 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3760: 0760 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3770: 0770 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3780: 0780 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3790: 0790 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3800: 0800 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3810: 0810 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3820: 0820 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3830: 0830 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3840: 0840 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3850: 0850 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3860: 0860 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3870: 0870 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3880: 0880 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3890: 0890 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3900: 0900 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3910: 0910 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3920: 0920 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3930: 0930 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3940: 0940 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3950: 0950 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3960: 0960 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3970: 0970 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3980: 0980 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 3990: 0990 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4000: 0100 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4010: 0110 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4020: 0120 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4030: 0130 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4040: 0140 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4050: 0150 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4060: 0160 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4070: 0170 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4080: 0180 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4090: 0190 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4100: 0200 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4110: 0210 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4120: 0220 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4130: 0230 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4140: 0240 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4150: 0250 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4160: 0260 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4170: 0270 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4180: 0280 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4190: 0290 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4200: 0300 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4210: 0310 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4220: 0320 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4230: 0330 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4240: 0340 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4250: 0350 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4260: 0360 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4270: 0370 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4280: 0380 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4290: 0390 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4300: 0400 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4310: 0410 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4320: 0420 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4330: 0430 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4340: 0440 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4350: 0450 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4360: 0460 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4370: 0470 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4380: 0480 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4390: 0490 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4400: 0500 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4410: 0510 20 9F 01 LDATM \$18 CLEAR SCREEN COMMAND
 4420: 0520 20 9F 0

```

0420:           BNE  NYY
                LD=13
0010:           OUTPUT <CR> CR <LF> TO TV
0020:           OUTPUT <CR> CR <LF> TO TV
0030:           CRLFTV LDA CCMAX      MOVE CURSOR ALL THE WAY RIGHT
                CLC
                CLRPO
0040:           AD 72 01 CRLFTV LDA CCMAX      MOVE CURSOR + (LINMAX - CURPC)
                CLC
                CLRPO
0050:           0172 18 01 CRTC      CURSOR CURSOR + (LINMAX - CURPC)
                ADC
                STA
                CURPO
0060:           0176 71 01 CRTC      CURSOR CURSOR + (LINMAX - CURPC)
                SBC
                CURPO
0070:           0179 18 01 CRTC      CURSOR CURSOR + (LINMAX - CURPC)
                ADC
                STA
                CURPO
0080:           017A 65 F0 CRTC      CURSOR CURSOR + (LINMAX - CURPC)
                STA
                CURPO
0090:           017C 85 F0 CRTC      CURSOR CURSOR + (LINMAX - CURPC)
                STA
                CURPO
0100:           017E 90 02 CRTC      CURSOR CURSOR + (LINMAX - CURPC)
                BCC
                CURPO
0110:           0180 36 F1 INC       CURSOR +01
                STA
                CURPO
0120:           0182 A9 00 CRTC      LDAIM $00
                STA
                CURPO
0130:           0184 2C 75 01 BVS      ASK AIM/SYM/KIM ?
                STA
                CURPO
0140:           0187 70 05 BVS      ASK AIM/SYM/KIM ?
                STA
                CURPO
0150:           0189 30 03 BMT      SYM
                STA
                CURPOZ
0160:           018B 8D 15 A4 CRTVS     CLEAR DISPLAY PCINTER (AIM)
                STA
                CURPOZ
0170:           018E B8 CRTVS     CLEAR DISPLAY PCINTER (AIM)
                STA
                CURPOZ
0180:           018F 8D 70 01 CURPIM    CLEAN UP BIT ASK
                STA
                CURPOZ
0190:           0192 8D 71 01 CURPIM    CLR DISP PNTR
                STA
                CURPOZ
0200:           0195 20 65 03 CURRIG   JSR STCHB
                STA
                CURPOZ
0210:           0198 EA NOP
                STA
                CURPOZ
0220:           0199 EA NOP
                STA
                CURPOZ
0230:           019A 4C 53 02 JMP      ENTCHA
                STA
                CURPOZ
0240:           019D EA NOP
                STA
                CURPOZ
0250:           019E EA NOP
                STA
                CURPOZ
0260:
0270:
0280:           AIM/SYM/KIM OUTPUT VECTORED HERE
0290:           ENTRY POINT
                OUTPUT A CHARACTER TO TV
0300:
0310:
0320:           CUTTV PHA
                STA
                CURPOZ
0330:           019F 48 CUTTV PHA
                STA
                CURPOZ
0340:           01A0 B8 CLV
                STA
                CURPOZ
0350:           01A1 83 7F 01 XTEMP
                STA
                CURPOZ
0360:           01A4 8C 80 01 YTEMP
                STA
                CURPOZ
0370:           01A7 A4 F1 LDY      CURSOR +01 TEST FOR RANGE
                STA
                CURPOZ
0380:           01A9 CC 74 01 CPY      RAMEND CURSOR BELOW MAXIMUM ?
                STA
                CURPOZ
0390:           01AC B0 5A BCS      HOMEX NO. HOME AND RETURN
                STA
                CURPOZ
0400:           01AE CC 73 01 CPY      RAMPAG IS CURSOR ABCVE MINIMUM ?
                STA
                CURPOZ
0410:           01B1 90 55 BCC      HOMEX NO. HOME CURSCR
                STA
                CURPOZ
0420:           01B3 A8 TAY
                STA
                CURPOZ
0430:           01B4 AD 75 01 LDA      ASK TEST PCG FLAG, BIT 2
                STA
                CURPOZ
0440:           01B7 4A LSRA
                STA
                CURPOZ
0450:           01B8 4A TYA      RESTORE CHARACTER
                STA
                CURPOZ
0460:           01B9 98 BCS      CUTNXT IF BIT SET, DC NOT STRIP
                STA
                CURPOZ
0470:           01BA B0 02 ANDTM $7F IF NOT SET, CONVERT CHARACTER
                STA
                CURPOZ
0480:           01BC 29 7F TAY
                STA
                CURPOZ
0490:           IT IS A COMMAND, NOW WHICH CNE
0500:
0510:           OUTNXT TAY
                STA
                CURPOZ
0520:           01BF A8 CMPIM $0D
                STA
                CURPOZ
0530:           01BF C9 3D CMPIM $0D
                STA
                CURPOZ
0540:           01C1 F0 AF BEQ      CRLFPT
                STA
                CURPOZ
0550:           01C3 C9 10 CMPIM $10
                STA
                CURPOZ

0560:           01C5 D0 04 BNE  NYY
                LD=13
0570:           01C7 A9 02 LDATM $02
                STA
                CURPOZ
0580:           01C9 D0 06 BN3
                STA
                CURPOZ
0590:           01CB C9 01 CMPIM $01
                STA
                CURPOZ
                **** ERASE TO THE END OF SCREEN ****
0600:           01CD D0 0A LDATM $01
                STA
                CURPOZ
0610:           01CF A9 01 EOR      ASK
                STA
                CURPOZ
0620:           01D1 4D 75 01 TGL
                STA
                CURPOZ
0630:           01D4 8D 75 01 STA
                STA
                CURPOZ
0640:           01D7 50 25 BVC      HOMAX
                STA
                CURPOZ
0650:           01D9 C9 06 BN3
                STA
                CURPOZ
0660:           01DB D0 04 CMPIM $06
                STA
                CURPOZ
0670:           01DD A9 04 LDATM $04
                STA
                CURPOZ
0680:           01DF D0 F0 BN3
                STA
                CURPOZ
0690:           01E1 C9 11 NAA
                STA
                CURPOZ
0700:           01E3 D0 04 BN3
                STA
                CURPOZ
0710:           01E5 A9 08 LDATM $08
                STA
                CURPOZ
0720:           01E7 D0 E8 TGL
                STA
                CURPOZ
0730:           01E9 C9 05 BN3
                STA
                CURPOZ
0740:           01EB D0 13 CMPIM $05
                STA
                CURPOZ
0750:
0760:
0770:           01ED A5 F1 ECS
                STA
                CURSOR +01 SAVE CURSOR
0780:           01EF 48 00 LDA
                STA
                CURSOR
0790:           01F0 A5 F0 PHA
                STA
                CURSOR
0800:           01F2 48 00 LDA
                STA
                CURSOR
0810:           01F3 20 17 03 JSR
                STA
                SPACES
0820:           01F6 EA 00 NOP
                STA
                SPACES OFFSET
0830:           01F7 EA 00 NOP
                STA
                SPACES
0840:           01F8 68 PLA
                STA
                CURSOR RESTORE CURSOR
0850:           01F9 85 F0 PLA
                STA
                CURSOR
0860:           0200 C9 18 NTT
                STA
                CURSOR
0870:           01FB 68 PLA
                STA
                CURSOR
0880:           01FC 85 F1 STA
                STA
                CURSOR +01
0890:           01FE 50 5C BVC
                STA
                HOMAX
                HOMA
                EXIT ALWAYS
0900:           0200 C9 18 NTT
                STA
                CURSOR
0910:           0202 F0 68 BEQ
                STA
                CURSR CLRSCR
0920:           0204 C9 08 CMPIM $08
                STA
                CURSR H HOME CURSOR
0930:           0206 D0 02 BN3
                STA
                CURSR
0940:           0208 50 4D HOMEX
                STA
                CURSR
0950:           020A C9 13 NZZ
                STA
                CURSR
0960:           020C F0 72 BEQ
                STA
                CURSR S SCROLL UP
0970:           020E C9 12 CMPIM $12
                STA
                CURSR
0980:           0210 F0 66 BEQ
                STA
                CURSR R CURSOR RIGHT
0990:           0212 C9 04 CMPIM $04
                STA
                CURSR
1000:           0214 F0 64 BEQ
                STA
                CURSR DOWN
1010:           0216 C9 15 CMPIM $15
                STA
                CURSR UP
1020:           0218 F0 62 BEQ
                STA
                CURSR
1030:           021A C9 0C CMPIM $0C
                STA
                CURSR
1040:           021C F0 60 BEQ
                STA
                CURSR
1050:           021E C9 75 01 CMPIM $7F
                STA
                CURSR
1060:           0221 50 0E BT
                STA
                CURSR
1070:           0223 B8 TSTAS
                STA
                AIM CR SIM
                TEST KIM SPECIAL CODES
1080:           0224 C9 7F BEQ
                STA
                KIMST CLV
                DELETE = DELETE
1090:           0226 F0 18 CMPIM $0A
                STA
                KIMDEL
                LINEFEED = DOWN
1100:           0228 C9 0A CMPIM $0A
                STA
                KIMDEL
                LINEFEED = DOWN

```



```

0570: 02D4 EA NCP ENTCHA OFFSET 0170: STORE ROUTINE FIRST TESTS FOR AIM OR SYM
0560: 02D5 EA NCP
0590: **** MOVE CURSOR UP **** 0180: 0190: 0321 2C 75 01 STORE BIT ASK AIM/SYM/KIM
C600: CURUP LDA CURSR SUB LINMAX TO CURSOR 0200: 0324 70 2C BVS STCHAA KIM
0610: **** MOVE CURSOR UP CNE LINE 0220: 0326 30 2A BMI STCHAA SYM IGNORES AIM DELETS STUFF
0620: 02D6 A5 F0 CURUP SEC 0230: FIRST CHECK IF DELETE WAS KEYED.
0630: 02D8 38 STA SBC CCLMAX MOVE UP CNE LINE 0240: IF SC, A JSR PSL (DELETE SUBROUTINE) LOCATIONS
0640: 02D9 ED 72 01 BCS CURSOR HOMAXX UNDER FLOW OF PAGE 0250: FROM STACK PTR PLUS 4, 5 SHOULD BE $E7F2
0650: 02DC 65 F0 JSR DECRRA 0260: 0270: 0328 BA LDAX $0105 LOCK 5 PLACES UP FRM STACK PTR
0660: 02DE B0 25 NCP DECRA 0280: 0329 BD 05 01 TSX GET STACK PTR
0670: 02E0 20 E2 03 JMP ENTCHB 0290: 032C C9 E7 BNE STCHR IT IS NOT A DELETE
0680: 02E3 EA NCP ENTCHB OFFSET 0300: 032E D0 07 LDAX $0104 CHECK LOWER HALF OF ADDRESS
0690: 02E4 EA NCP NCP 0310: 0330 BD 04 01 CMPIM $F72
0700: 02E5 4C 55 02 NCP 0320: 0333 C9 F2 BEQ DELETE YES, DELETE ONE CHAR
0710: 02E8 EA NCP
0720: 02E9 EA NCP
0730: **** MOVE CURSOR TO THE RIGHT **** 0330: 0335 F0 62
0740: CURITE LDY CURPOZ INY 0340: STORE A CHAR IN RAM (4XXX) AND CHECK FOR CURSOR
0750: 02EA AC 71 01 CURPOZ INY 0350: 0360: 0337 98 STCHR TYA CHAR WAS SAVED IN Y
0770: 02ED C8 CPY CCLMAX TEST LIMIT 0360: 0370: 0337 98 STCHR TYA CHAR WAS SAVED IN Y
0780: 02EE CC 72 01 BCC CRX NOT EXCEEDED 0380: 0390: WRAP CURPOZ AROUND 20 TO BE ABLE TO
0790: 02F1 90 02 LDYIM $00 RESET IF EXCEEDED 0400: RECEIVE DELETES
0800: 02F3 A0 00 STY CURPOZ STORE NEW VALUE 0410: 0420: 0338 AC 15 A4 LDY CURPOZ DON'T LET CURPOZ >= 20 CHR
0810: 02F5 8C 71 01 CRX JMP CURRIG AND FINISH UP 0430: 033B C8 INY CPYIM $14 CURPOZ >= 20 ?
0820: 02FB EA NOP 0440: 033C C0 14 BCC XXA YES, INCR CURPOZ
0830: 02FB EA NOP 0450: 033E 90 02 LDYIM $13 NO, RESET TO 19
0840: 02FC EA NOP
0850:
0860: **** MOVE CURSOR TO THE LEFT **** 0460: 0340 A0 13 XXA STY CURPOZ
0870: 02FD 20 DA 03 CURLEF JSR DECREM 0470: 0342 8C 15 A4
0880: 02FD 20 DA 03 CURLEF JSR DECREM 0480: 0490: MAINTAIN DISPLAY BUFFER FOR EDITOR
0890: 0300 EA NOP
0900: 0301 EA NOP
0910: 0302 C3 71 01 DEC CURPOZ FIX CURSOR POSITION 0500: 0510: 0345 AC 70 01 LDY CURPRM IF > 60 DON'T PUT IN CN DISBUFFER
0920: 0305 4C 5C 02 HOMAXX JMP HOMA TRANSFER TO HOMA 0520: 0348 C0 3C CPYIM $3C
0930: 0306 EA NOP 0530: 034A B0 06 BCS STCHAA
0940: 0309 EA NOP 0540: 034C 99 18 A4 STAY DIBUFF EDITOR & M-COMMAND USE THIS
0950:
0960: ID=15 0550: 034F EE 70 01 INC CURPRM BUFFER
0560: 0570: WRAP AROUND LINMAX FOR CRT (START NEW LINE)
0580: SUBROUTINES
0010: 0316 60 RTS
0020: 030A A9 00 HOMECL LDATM $00 SET CURSR TO BEGINNING
0030: 030C 85 F0 STA CURSR CLR DISP PNTR
0040: 030E 6D 71 01 STA CURPOZ CLR DISP PNTR
0050: 0311 AD 73 01 LDA RAMPAG
0060: 0314 65 F1 STA CURSCR +01
0070: 0316 60 RTS
0080: 0317 A9 20 SPACES LDATM $20 PUT BLANKS
0090: 0319 20 61 03 JSR STCHA STCHA OFFSET
0100: 031D EA NCP SPACES LDATM $20 PUT BLANKS
0110: 0319 20 61 03 JSR STCHA STCHA OFFSET
0120: 031C 3A NCP SPACES LDATM $20 PUT BLANKS
0130: 031D EA NCP SPACES LDATM $20 PUT BLANKS
0140: 031E 20 F7 BNZ SPACES
0150: 0320 60 RTS
0160:

```

```

0730: 036F D0 06          BNE STCHS
0740: 0371 A5 F1          LDA CURSCR +01
0750: 0373 29 0F          ANDIM $0F
0760: 0375 C5 F5          CMP SCRLW +01 HIGH HALF
0770: 0377 60          STCHS RTS
0780:               TRANSFER CURSOR TO ACTUAL CURSOR IN
0790:               6845 AND TO AIM CURSOR
0810:               SET INDEX
0820: 0378 A0 00          TRANSF LDYIM $00
0830: 037A A9 0E          LDAIM $05 CURSCR HIGH
0840: 037C 91 F2          STAII CRTREG SETUP 6845
0850: 037E 36 F2          INC CRTREG
0860: 0380 A5 F1          LDA CURSOR +01
0870: 0382 29 0F          ANDIM $0F
0880: 0384 91 F2          STAII CRTREG
0890: 0386 C6 F2          DEC CRTREG
0900: 0388 A9 0F          LDAIM $0F CURSOR LOW
0910: 038A 91 F2          STAII CRTREG
0920: 038C E6 F2          INC CRTREG
0930: 038E A5 F0          LDA CURSCR
0940: 0390 91 F2          STAII CRTREG
0950: 0392 C6 F2          DEC CRTREG
0960: 0394 60          RTS
0970:               SYMDEL LDYIM $20 SPACE CHARACTER
0980: 0395 A0 20          BNE SDEL SKIP SOME AIM STUFF
0990: 0397 D0 0F
1000:               DELETE LDAX $0102 DON'T DECR BEYOND ZERO
1010: 0399 BD 02 01          CMPIM $14 Y REG >= 20 ?
1020: 039C C9 14          BCC XXC NO, RESET CURPC TO THAT VALUE
1030: 0393 90 02          LDAIM $13 YES, RESET TO 19 TO SEE DELETES
1040: 03A0 A9 13          STA CURPOZ
1050: 03A2 8D 15 A4          XXC DEC CURPRM DEC OTHER POINTER
1060: 03A5 CE 70 01          DEC CURPRM WRAP AROUND ZERC
1070: 03A8 CE 71 01          DELA BPL DELA
1080: 03AB 10 09          COLMAX RESET
1090: 03AD AD 72 01          LDA CURPC
1100: 03B0 8D 71 01          STA CURPC
1110: 03B3 C3 71 01          DEC CURPC SET TO COMAX - 1
1120: 03B6 2C 75 01          DELA BIT ASK AIM/SYM/KIM
1130: 03B9 70 12          SDELA BVS SDELA KIM
1140: 03BB 30 10          BMI SDELA SYM
1150: 03BD A9 38          LDAIM $38 STORE NEW RTN ADDRESS FOR OUTDP1 - AIM
1160: 03BF 9D 05 01          LDAIM $0105 RTN TO PSL00+3 WITH NEW POINTER
1170: 03C2 A9 04          LDAIM $04 CURPRM NEW PCINT TO SAVED ACC
1180: 03C4 9D 04 01          STAX $0104
1190: 03C7 AD 70 01          LDA CURPRM
1200: 03CA 9D 03 01          STAX $0103 CLV CLEAR FROM BIT ASK
1210: 03CD B8          SDELA JSR DECREM
1220: 03C3 20 DA 03          NCP DECREM OFFSET
1230: 03D1 EA          NCP
1240: 03D2 EA          NCP
1250: 03D3 96          TYA CLEAR LAST CHAR
1260: 03D4 A0 00          LDYIM $00
1270: 03D6 91 F0          STATI CURSOR
1260: 03D8 C6          INY SET Z FLAG TC 1

```

```

0010: 0400          CRG    $0400  NOT REQUIRED FOR CUTPUT
0020: 0400          CRG    $0400  NOT REQUIRED FOR CUTPUT
0030:          LDAIM  KBINIT KBTEST SETUP :INSVEC
0040: 0400 A9 7D          CLC
0050: 0402 18          ADC    JUMP  +01 OFFSET
0060: 0403 62 79 01          TAX
0070: 0406 AA          LDAIM KBTEST / PAGE
0080: 0407 A9 04          ADC    JUMP  +02
0090: 0409 6D 7A 01          BIT   ASK  AIM/SYM/KIM ?
0100: 040C 2C 75 01          BVS   KIMA
0110: 040F 70 0D          BPL   KBDA
0120: 0411 10 14          BPL   KBDA
0130: 0413 20 86 6B          JSR   ACCESS SYM
0140: 0416 8E 67 A6          STX   INSPEC +01
0150: 0419 8D 68 A6          STA   INSPEC +02
0160: 041C 50 09          BVC   KBDA
0170:          LDYIM $01  STORE KEYBOARD TEST VECTOR
0180: 041E B6          KIMA
0190: 041F A0 01          LDYIM $01  STORE KEYBOARD TEST VECTOR
0200: 0421 91 02          STAY KTST VIA TEMPORARY PAGE ZERO POINTER
0210: 0423 88          DEY
0220: 0424 6A          TXA
0230: 0425 91 02          STAY KTST STORE LOW HALF OF ADDRESS
0240:          LDYIM KBWAIT SETUP INPUT VECTOR
0250: 0427 A9 8E          KBDA
0260: 0429 18          CLC
0270: 042A 6D 79 01          ADC    JUMP  +01
0280: 042D AA          TAX   SAVE LOW ADDRESS
0290: 042E A9 04          ADC    JUMP  +02
0300: 0430 6D 7A 01          BIT   ASK  AIM/SYM/KIM ?
0310: 0433 2C 75 01          BVS   KIM
0320: 0436 70 0A          BPL   KBDB
0330: 0438 10 12          STA   INVEC +01 LOW VECTOR
0340: 043A 8E 61 A6          STA   INVEC +02 HIGH VECTOR FOR SYM
0350: 043D 8D 62 A6          BNE   KBDC
0360: 0440 D0 10          BNE   KBDC
0370:          LDYIM $01  STORE HIGH HALF OF KEYBOARD
0380: 0442 B8          KIMB
0390: 0443 C8          CLV
0400: 0444 91 04          STAY KIN ADDRESS VIA TEMP. KIN PCUTER
0410: 0446 88          DEY
0420: 0447 8A          TXA
0430: 0446 91 04          STAY KIN STORE HIGH HALF
0440: 044A 50 06          BVC   KBDC
0450: 044C 8E 06 01          STX   UIN LOW VECTOR FOR AIM
0460: 044E 6D 09 01          STA   UIN +01 HIGH VECTOR
0470: 0452 A9 7F          KBDC
0480: 0454 A0 1E          LDYIM $7F
0490: 0456 91 F2          LDYIM $1E
0500: 0458 A9 FF          LDYIM $FF
0510: 045A A0 1D          LDYIM $1D
0520: 045C 91 F2          LDYIM $00
0530: 0453 A9 20          LDYIM $13
0540: 0460 A0 13          LDYIM $13
0550: 0462 91 F2          LDYIM $C1
0560: 0464 A9 01          LDYIM $1B

0570: 0466 A0 1B          LDYIM $1B
0580: 0468 91 F2          STAY CRTREG LATCH KEYBOARD DATA
0590: 046A A9 C6          LDAIM $C6
0600: 046C A0 1C          LDYIM $1C
0610: 046E 91 F2          STAY CRTREG KBRD POS, SUPPRESS CONTROL CODES
0620: 0470 AD 75 01          LDA   ASK AIM/SYM/KIM
0630: 0473 10 03          BPL   INDONE AIM/KIM
0640: 0475 20 9C 8B          LDYIM NACCS SYM
0650: 0478 29 40          LDYIM ANDIM $40
0660: 047A D0 11          LDYIM ANDIM $40
0670: 047C 00          LDYIM ANDIM $40
0680:          LDYIM $02  MASK TO CA1 FLAG
0690: 047D 8C 80 01          LDYIM $02  MASK TO CA1 FLAG
0700: 0480 18          LDYIM $02  MASK TO CA1 FLAG
0710: 0481 A0 1D          LDYIM $02  MASK TO CA1 FLAG
0720: 0483 B1 F2          LDYIM $02  MASK TO CA1 FLAG
0730: 0485 29 02          LDYIM $02  MASK TO CA1 FLAG
0740: 0487 F9 01          LDYIM $02  MASK TO CA1 FLAG
0750: 0489 38          LDYIM $02  MASK TO CA1 FLAG
0760: 048A AC 80 01          LDYIM $02  MASK TO CA1 FLAG
0770: 048D 60          LDYIM $02  MASK TO CA1 FLAG
0780:          LDYIM $02  TEST DATA PRESENT
0790: 048E 8C 80 01          LDYIM $02  TEST DATA PRESENT
0800: 0491 2C 75 01          LDYIM $02  TEST DATA PRESENT
0810: 0494 70 04          LDYIM $02  TEST DATA PRESENT
0820: 0496 30 02          LDYIM $02  TEST DATA PRESENT
0830: 0498 90 F0          LDYIM $02  TEST DATA PRESENT
0840: 049A B8          LDYIM $02  TEST DATA PRESENT
0850: 049B A0 1D          LDYIM $02  TEST DATA PRESENT
0860: 049D B1 F2          LDYIM $02  TEST DATA PRESENT
0870: 049F 29 02          LDYIM $02  TEST DATA PRESENT
0880: 04A1 F0 F7          LDYIM $02  TEST DATA PRESENT
0890: 04A3 A0 11          LDYIM $02  TEST DATA PRESENT
0900: 04A5 B1 F2          LDYIM $02  TEST DATA PRESENT
0910: 04A7 A8          LDYIM $02  TEST DATA PRESENT
0920:          LDYIM $02  TEST DATA PRESENT
0930: 04A8 C9 1A          LDYIM $02  TEST DATA PRESENT
0940: 04AA D0 0B          LDYIM $02  TEST DATA PRESENT
0950: 04AC A0 00          LDYIM $02  TEST DATA PRESENT
0960: 04AE B1 F0          LDYIM $02  TEST DATA PRESENT
0970: 04B0 AC 75 01          LDYIM $02  TEST DATA PRESENT
0980: 04B3 10 3D          LDYIM $02  TEST DATA PRESENT
0990: 04B5 30 33          LDYIM $02  TEST DATA PRESENT
1000:          LDYIM $02  TEST DATA PRESENT
1010: 04B7 AD 75 01          LDYIM $02  TEST DATA PRESENT
1020: 04BA 4A          LDYIM $02  TEST DATA PRESENT
1030: 04BB 98          LDYIM $02  TEST DATA PRESENT
1040: 04BC B0 0A          LDYIM $02  TEST DATA PRESENT
1050: 04BE C9 61          LDYIM $02  TEST DATA PRESENT
1060: 04C0 90 06          LDYIM $02  TEST DATA PRESENT
1070: 04C2 C9 7B          LDYIM $02  TEST DATA PRESENT
1080: 04C4 B0 02          LDYIM $02  TEST DATA PRESENT
1090: 04C6 29 DF          LDYIM $02  TEST DATA PRESENT
1100: 04C8 AC 75 31          LDYIM $02  TEST DATA PRESENT
1110: 04CB 10 06          LDYIM $02  TEST DATA PRESENT
1120: 04CB          LDYIM $02  TEST DATA PRESENT

0570:          LDYIM $1A  CTRL Z ?
0580:          BNE   KNCRM NO
0590:          LDYIM $00  READ FROM CURRENT CURSOR
0600:          LDYIM CURSOR POSITION
0610:          LDYIM $61  NOTUP IF SET, NOT UPPER ONLY
0620:          BCS   TYA
0630:          LDYIM $7B  NOTUP NOT LOWER CASE ALPHA
0640:          BCS   CMPIM $61
0650:          LDYIM $7B  NOTUP NOT LOWER CASE ALPHA
0660:          BCS   LDYIM $11  READ DATA
0670:          LDYIM $11  WAIT FOR IT
0680:          BPL   KIMOUT AIM OR KIM WITHOUT ECHO
0690:          BPL   UCUT SIM WITHOUT ECHO
0700:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0710:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0720:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0730:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0740:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0750:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0760:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0770:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0780:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0790:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0800:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0810:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0820:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0830:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0840:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0850:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0860:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0870:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0880:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0890:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0900:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0910:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0920:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0930:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0940:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0950:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0960:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0970:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0980:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
0990:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
1000:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
1010:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
1020:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
1030:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
1040:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
1050:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
1060:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
1070:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
1080:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
1090:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
1100:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
1110:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG
1120:          LDYIM $02  TEST UPPER/LOWER ASCII FLAG

```

```

0010: 04CD 2C 53 A6      BIT    TECHC  ECHO FLAG IN SYM
0020: 0500      ORG   $0500
0030:          THIS CODE DOES NOT HAVE TO BE RESIDENT
0040:          AFTER IT IS INITIALLY RUN
0050:          THIS SETUP PROGRAM MUST BE RUN FIRST TO GET
0060:          THE RELOCATION FACILITY SETUP.

A REGISTER MUST CONTAIN RETURN INFO:

0070: 04D0 B6      CLV    JUST IN CASE
0080: 04D1 30 09      BME    YES, ECHO BIT SET
0090: 04D3 A6      AUCUT  SAVE CHARACTER
0100: 04D4 A9 24      LDATH $04        TEST ECHO FLAG
0110: 04D6 2D 75 01      AND   ASK     TOGGLE BY CTRL F
0120: 04D9 F0 0A      BEQ    ALLST NC ECHO IF ZEROC
0130: 04DB 96      TYA    RESTORE CHARACTER
0140: 04DC 20 9F 01      JSR    OUTTY  ECHO TO VIDEO
0150: 04DF EA      NCP    -
0160: 04E0 EA      NOP    -
0170: 04E1 C0 06      CPYIM $06      WAS IT A CTRL F TO TURN OFF ECHO?
0180: 04E3 00 00      BEQ    KGET   IF SO, DO NOT ECHO TO USER
0190: 04E3 3F B5      ASK    AIMKTM
0200: 04E5 AC 75 31      ALLST LDY
0210: 04E8 10 07      BPL    ALLOUT AIMKTM
0220: 04E9 00 00      SAVE CHARACTER
0230: 04EA AB      TAY    MODIFY RETURN TO AVOID THE
0240: 04EB 68      PLA    AUTOMATIC LOWER CASE TO UPPER CASE
0250: 04EC 18      CLC    CONVERSION
0260: 04ED 69 0C      ADCTM $0C      NEW RETURN ADDRESS
0270: 04EF 48      PHA    SET CARRY FOR DATA
0280: 04F0 36      SEC    -
0290: 04F1 98      ALLOUT TYA  RESTORE CHARACTER
0300: 04F2 B8      KIMCUT CLV
0310: 04F3 AC 80 01      LDY    YTEMP
0320: 04F6 60      RTS    -
0330: 04F7 60      RTS    -
0340: 04F8 60      RTS    -
0350: 04F9 60      RTS    -
0360: 04FA 60      RTS    -
0370: 04FB 60      RTS    -
0380: 04FC 60      RTS    -
0390: 04FD 60      RTS    -
0400: 04FE 60      RTS    -
0410: 04FF 60      RTS    -
0420: 0500 48      LDA    ECHO FLAG IN SYM
0430: 0501 48      LDA    CLEAR ALL STATUS FLAGS
0440: 0502 48      LDA    MAKE A SUBROUTINE RETURN
0450: 0503 48      LDA    CREATE SUBROUTINE RETURN
0460: 0504 28      LDA    GO AND RETURN
0470: 0505 A9 60      STA    LRT
0480: 0506 85 F6      STA    STACK POINTER
0490: 0507 20 F6 00      JSR    PUSH STACK PTRINTER BACK DCWN TO
0500: 0508 00 00      TSX    THE RETURN ADDRESSES
0510: 0509 20 F6 00      JSR    LOW RETURN ADDRESS
0520: 050A 00 00      TSX    FIX UP POINTERS
0530: 050B 00 00      SEC    +0B CORRECT POINTER
0540: 050C BA      SBCTM SETUP
0550: 050D CA      STA    JUMP +01 STORE LOW
0560: 050E CA      DEX    HIGH ADDRESS OF JUMP
0570: 050F 9A      PLA    / PAGE OFFSET
0580: 0510 68      SBCTM SETUP
0590: 0511 38      STA    PHA    SAVE
0600: 0512 E9 0B      STA    JUMP +02
0610: 0513 00 00      STA    JUMP +03
0620: 0514 8D 79 01      STA    JUMP +04
0630: 0515 68      PLA    -
0640: 0516 89 05      STA    JUMP +05
0650: 0517 68      STA    JUMP +06
0660: 0518 89 05      STA    JUMP +07
0670: 0519 48      STA    JUMP +08
0680: 051A 48      STA    JUMP +09
0690: 051B 8D 7A 01      STA    JUMP +0A
0700: 051C 48      STA    JUMP +0B
0710: 051D 8D 7A 01      STA    JUMP +0C
0720: 051E AD 79 01      LDA    JUMP +01 NOW SETUP SUBROUTINE SERVICE
0730: 0521 18      CLC    -
0740: 0522 69 05      ADCIM $05      FIVE BYTES BEYOND JUMP
0750: 0523 00 00      STA    SUBR +01
0760: 0524 8D 7C 01      STA    SUBR +
0770: 0525 4C 00      STA    SUBR +
0780: 0526 8D 7D 01      STA    SUBR +
0790: 0527 68      PLA    HIGH
0800: 0528 69 00      ADCIM $00      CARRY IF ANY
0810: 0529 8D 7D 01      STA    SUBR +02
0820: 052A 4C 00      LDATM $4C      JMP COMMAND
0830: 052B 8D 76 01      STA    SUBR +
0840: 052C 8D 7B 01      STA    SUBR +
0850: 052D 8D 7B 01      STA    SUBR +
0860: 052E 8D 7B 01      STA    SUBR +
0870: 052F 8D 7B 01      STA    SUBR +
0880: 0530 8D 7B 01      STA    SUBR +
0890: 0531 8D 7B 01      STA    SUBR +
0900: 0532 8D 7B 01      STA    SUBR +
0910: 0533 8D 7B 01      STA    SUBR +
0920: 0534 8D 7B 01      STA    SUBR +
0930: 0535 8D 7B 01      STA    SUBR +
0940: 0536 8D 7B 01      STA    SUBR +
0950: 0537 8D 7B 01      STA    SUBR +
0960: 0538 8D 7B 01      STA    SUBR +
0970: 0539 8D 7B 01      STA    SUBR +
0980: 053A 8D 7B 01      STA    SUBR +
0990: 053B 8D 7B 01      STA    SUBR +
0100: 053C 8D 7B 01      STA    SUBR +
0101: 053D 8D 7B 01      STA    SUBR +
0102: 053E 8D 7B 01      STA    SUBR +
0103: 053F 8D 7B 01      STA    SUBR +
0104: 0540 8D 7B 01      STA    SUBR +
0105: 0541 8D 7B 01      STA    SUBR +
0106: 0542 8D 7B 01      STA    SUBR +
0107: 0543 8D 7B 01      STA    SUBR +
0108: 0544 8D 7B 01      STA    SUBR +
0109: 0545 8D 7B 01      STA    SUBR +
0110: 0546 8D 7B 01      STA    SUBR +
0111: 0547 8D 7B 01      STA    SUBR +
0112: 0548 8D 7B 01      STA    SUBR +
0113: 0549 8D 7B 01      STA    SUBR +
0114: 054A 8D 7B 01      STA    SUBR +
0115: 054B 8D 7B 01      STA    SUBR +
0116: 054C 8D 7B 01      STA    SUBR +
0117: 054D 8D 7B 01      STA    SUBR +
0118: 054E 8D 7B 01      STA    SUBR +
0119: 054F 8D 7B 01      STA    SUBR +
0120: 0550 8D 7B 01      STA    SUBR +
0121: 0551 8D 7B 01      STA    SUBR +
0122: 0552 8D 7B 01      STA    SUBR +
0123: 0553 8D 7B 01      STA    SUBR +
0124: 0554 8D 7B 01      STA    SUBR +
0125: 0555 8D 7B 01      STA    SUBR +
0126: 0556 8D 7B 01      STA    SUBR +
0127: 0557 8D 7B 01      STA    SUBR +
0128: 0558 8D 7B 01      STA    SUBR +
0129: 0559 8D 7B 01      STA    SUBR +
0130: 055A 8D 7B 01      STA    SUBR +
0131: 055B 8D 7B 01      STA    SUBR +
0132: 055C 8D 7B 01      STA    SUBR +
0133: 055D 8D 7B 01      STA    SUBR +
0134: 055E 8D 7B 01      STA    SUBR +
0135: 055F 8D 7B 01      STA    SUBR +
0136: 0560 8D 7B 01      STA    SUBR +
0137: 0561 8D 7B 01      STA    SUBR +
0138: 0562 8D 7B 01      STA    SUBR +
0139: 0563 8D 7B 01      STA    SUBR +
0140: 0564 8D 7B 01      STA    SUBR +
0141: 0565 8D 7B 01      STA    SUBR +
0142: 0566 8D 7B 01      STA    SUBR +
0143: 0567 8D 7B 01      STA    SUBR +
0144: 0568 8D 7B 01      STA    SUBR +
0145: 0569 8D 7B 01      STA    SUBR +
0146: 056A 8D 7B 01      STA    SUBR +
0147: 056B 8D 7B 01      STA    SUBR +
0148: 056C 8D 7B 01      STA    SUBR +
0149: 056D 8D 7B 01      STA    SUBR +
0150: 056E 8D 7B 01      STA    SUBR +
0151: 056F 8D 7B 01      STA    SUBR +
0152: 0570 8D 7B 01      STA    SUBR +
0153: 0571 8D 7B 01      STA    SUBR +
0154: 0572 8D 7B 01      STA    SUBR +
0155: 0573 8D 7B 01      STA    SUBR +
0156: 0574 8D 7B 01      STA    SUBR +
0157: 0575 8D 7B 01      STA    SUBR +
0158: 0576 8D 7B 01      STA    SUBR +
0159: 0577 8D 7B 01      STA    SUBR +
0160: 0578 8D 7B 01      STA    SUBR +
0161: 0579 8D 7B 01      STA    SUBR +
0162: 057A 8D 7B 01      STA    SUBR +
0163: 057B 8D 7B 01      STA    SUBR +
0164: 057C 8D 7B 01      STA    SUBR +
0165: 057D 8D 7B 01      STA    SUBR +
0166: 057E 8D 7B 01      STA    SUBR +
0167: 057F 8D 7B 01      STA    SUBR +
0168: 0580 8D 7B 01      STA    SUBR +
0169: 0581 8D 7B 01      STA    SUBR +
0170: 0582 8D 7B 01      STA    SUBR +
0171: 0583 8D 7B 01      STA    SUBR +
0172: 0584 8D 7B 01      STA    SUBR +
0173: 0585 8D 7B 01      STA    SUBR +
0174: 0586 8D 7B 01      STA    SUBR +
0175: 0587 8D 7B 01      STA    SUBR +
0176: 0588 8D 7B 01      STA    SUBR +
0177: 0589 8D 7B 01      STA    SUBR +
0178: 058A 8D 7B 01      STA    SUBR +
0179: 058B 8D 7B 01      STA    SUBR +
0180: 058C 8D 7B 01      STA    SUBR +
0181: 058D 8D 7B 01      STA    SUBR +
0182: 058E 8D 7B 01      STA    SUBR +
0183: 058F 8D 7B 01      STA    SUBR +
0184: 0590 8D 7B 01      STA    SUBR +
0185: 0591 8D 7B 01      STA    SUBR +
0186: 0592 8D 7B 01      STA    SUBR +
0187: 0593 8D 7B 01      STA    SUBR +
0188: 0594 8D 7B 01      STA    SUBR +
0189: 0595 8D 7B 01      STA    SUBR +
0190: 0596 8D 7B 01      STA    SUBR +
0191: 0597 8D 7B 01      STA    SUBR +
0192: 0598 8D 7B 01      STA    SUBR +
0193: 0599 8D 7B 01      STA    SUBR +
0194: 059A 8D 7B 01      STA    SUBR +
0195: 059B 8D 7B 01      STA    SUBR +
0196: 059C 8D 7B 01      STA    SUBR +
0197: 059D 8D 7B 01      STA    SUBR +
0198: 059E 8D 7B 01      STA    SUBR +
0199: 059F 8D 7B 01      STA    SUBR +
0200: 05A0 8D 7B 01      STA    SUBR +
0201: 05A1 8D 7B 01      STA    SUBR +
0202: 05A2 8D 7B 01      STA    SUBR +
0203: 05A3 8D 7B 01      STA    SUBR +
0204: 05A4 8D 7B 01      STA    SUBR +
0205: 05A5 8D 7B 01      STA    SUBR +
0206: 05A6 8D 7B 01      STA    SUBR +
0207: 05A7 8D 7B 01      STA    SUBR +
0208: 05A8 8D 7B 01      STA    SUBR +
0209: 05A9 8D 7B 01      STA    SUBR +
0210: 05AA 8D 7B 01      STA    SUBR +
0211: 05AB 8D 7B 01      STA    SUBR +
0212: 05AC 8D 7B 01      STA    SUBR +
0213: 05AD 8D 7B 01      STA    SUBR +
0214: 05AE 8D 7B 01      STA    SUBR +
0215: 05AF 8D 7B 01      STA    SUBR +
0216: 05B0 8D 7B 01      STA    SUBR +
0217: 05B1 8D 7B 01      STA    SUBR +
0218: 05B2 8D 7B 01      STA    SUBR +
0219: 05B3 8D 7B 01      STA    SUBR +
0220: 05B4 8D 7B 01      STA    SUBR +
0221: 05B5 8D 7B 01      STA    SUBR +
0222: 05B6 8D 7B 01      STA    SUBR +
0223: 05B7 8D 7B 01      STA    SUBR +
0224: 05B8 8D 7B 01      STA    SUBR +
0225: 05B9 8D 7B 01      STA    SUBR +
0226: 05BA 8D 7B 01      STA    SUBR +
0227: 05BB 8D 7B 01      STA    SUBR +
0228: 05BC 8D 7B 01      STA    SUBR +
0229: 05BD 8D 7B 01      STA    SUBR +
0230: 05BE 8D 7B 01      STA    SUBR +
0231: 05BF 8D 7B 01      STA    SUBR +
0232: 05C0 8D 7B 01      STA    SUBR +
0233: 05C1 8D 7B 01      STA    SUBR +
0234: 05C2 8D 7B 01      STA    SUBR +
0235: 05C3 8D 7B 01      STA    SUBR +
0236: 05C4 8D 7B 01      STA    SUBR +
0237: 05C5 8D 7B 01      STA    SUBR +
0238: 05C6 8D 7B 01      STA    SUBR +
0239: 05C7 8D 7B 01      STA    SUBR +
0240: 05C8 8D 7B 01      STA    SUBR +
0241: 05C9 8D 7B 01      STA    SUBR +
0242: 05CA 8D 7B 01      STA    SUBR +
0243: 05CB 8D 7B 01      STA    SUBR +
0244: 05CC 8D 7B 01      STA    SUBR +
0245: 05CD 8D 7B 01      STA    SUBR +
0246: 05CE 8D 7B 01      STA    SUBR +
0247: 05CF 8D 7B 01      STA    SUBR +
0248: 05D0 8D 7B 01      STA    SUBR +
0249: 05D1 8D 7B 01      STA    SUBR +
0250: 05D2 8D 7B 01      STA    SUBR +
0251: 05D3 8D 7B 01      STA    SUBR +
0252: 05D4 8D 7B 01      STA    SUBR +
0253: 05D5 8D 7B 01      STA    SUBR +
0254: 05D6 8D 7B 01      STA    SUBR +
0255: 05D7 8D 7B 01      STA    SUBR +
0256: 05D8 8D 7B 01      STA    SUBR +
0257: 05D9 8D 7B 01      STA    SUBR +
0258: 05DA 8D 7B 01      STA    SUBR +
0259: 05DB 8D 7B 01      STA    SUBR +
0260: 05DC 8D 7B 01      STA    SUBR +
0261: 05DD 8D 7B 01      STA    SUBR +
0262: 05DE 8D 7B 01      STA    SUBR +
0263: 05DF 8D 7B 01      STA    SUBR +
0264: 05E0 8D 7B 01      STA    SUBR +
0265: 05E1 8D 7B 01      STA    SUBR +
0266: 05E2 8D 7B 01      STA    SUBR +
0267: 05E3 8D 7B 01      STA    SUBR +
0268: 05E4 8D 7B 01      STA    SUBR +
0269: 05E5 8D 7B 01      STA    SUBR +
0270: 05E6 8D 7B 01      STA    SUBR +
0271: 05E7 8D 7B 01      STA    SUBR +
0272: 05E8 8D 7B 01      STA    SUBR +
0273: 05E9 8D 7B 01      STA    SUBR +
0274: 05EA 8D 7B 01      STA    SUBR +
0275: 05EB 8D 7B 01      STA    SUBR +
0276: 05EC 8D 7B 01      STA    SUBR +
0277: 05ED 8D 7B 01      STA    SUBR +
0278: 05EE 8D 7B 01      STA    SUBR +
0279: 05EF 8D 7B 01      STA    SUBR +
0280: 05F0 8D 7B 01      STA    SUBR +
0281: 05F1 8D 7B 01      STA    SUBR +
0282: 05F2 8D 7B 01      STA    SUBR +
0283: 05F3 8D 7B 01      STA    SUBR +
0284: 05F4 8D 7B 01      STA    SUBR +
0285: 05F5 8D 7B 01      STA    SUBR +
0286: 05F6 8D 7B 01      STA    SUBR +
0287: 05F7 8D 7B 01      STA    SUBR +
0288: 05F8 8D 7B 01      STA    SUBR +
0289: 05F9 8D 7B 01      STA    SUBR +
0290: 05FA 8D 7B 01      STA    SUBR +
0291: 05FB 8D 7B 01      STA    SUBR +
0292: 05FC 8D 7B 01      STA    SUBR +
0293: 05FD 8D 7B 01      STA    SUBR +
0294: 05FE 8D 7B 01      STA    SUBR +
0295: 05FF 8D 7B 01      STA    SUBR +
0296: 0500 8D 7B 01      STA    SUBR +
0297: 0501 8D 7B 01      STA    SUBR +
0298: 0502 8D 7B 01      STA    SUBR +
0299: 0503 8D 7B 01      STA    SUBR +
0300: 0504 8D 7B 01      STA    SUBR +
0301: 0505 8D 7B 01      STA    SUBR +
0302: 0506 8D 7B 01      STA    SUBR +
0303: 0507 8D 7B 01      STA    SUBR +
0304: 0508 8D 7B 01      STA    SUBR +
0305: 0509 8D 7B 01      STA    SUBR +
0306: 050A 8D 7B 01      STA    SUBR +
0307: 050B 8D 7B 01      STA    SUBR +
0308: 050C 8D 7B 01      STA    SUBR +
0309: 050D 8D 7B 01      STA    SUBR +
0310: 050E 8D 7B 01      STA    SUBR +
0311: 050F 8D 7B 01      STA    SUBR +
0312: 0510 8D 7B 01      STA    SUBR +
0313: 0511 8D 7B 01      STA    SUBR +
0314: 0512 8D 7B 01      STA    SUBR +
0315: 0513 8D 7B 01      STA    SUBR +
0316: 0514 8D 7B 01      STA    SUBR +
0317: 0515 8D 7B 01      STA    SUBR +
0318: 0516 8D 7B 01      STA    SUBR +
0319: 0517 8D 7B 01      STA    SUBR +
0320: 0518 8D 7B 01      STA    SUBR +
0321: 0519 8D 7B 01      STA    SUBR +
0322: 051A 8D 7B 01      STA    SUBR +
0323: 051B 8D 7B 01      STA    SUBR +
0324: 051C 8D 7B 01      STA    SUBR +
0325: 051D 8D 7B 01      STA    SUBR +
0326: 051E 8D 7B 01      STA    SUBR +
0327: 051F 8D 7B 01      STA    SUBR +
0328: 0520 8D 7B 01      STA    SUBR +
0329: 0521 8D 7B 01      STA    SUBR +
0330: 0522 8D 7B 01      STA    SUBR +
0331: 0523 8D 7B 01      STA    SUBR +
0332: 0524 8D 7B 01      STA    SUBR +
0333: 0525 8D 7B 01      STA    SUBR +
0334: 0526 8D 7B 01      STA    SUBR +
0335: 0527 8D 7B 01      STA    SUBR +
0336: 0528 8D 7B 01      STA    SUBR +
0337: 0529 8D 7B 01      STA    SUBR +
0338: 052A 8D 7B 01      STA    SUBR +
0339: 052B 8D 7B 01      STA    SUBR +
0340: 052C 8D 7B 01      STA    SUBR +
0341: 052D 8D 7B 01      STA    SUBR +
0342: 052E 8D 7B 01      STA    SUBR +
0343: 052F 8D 7B 01      STA    SUBR +
0344: 0530 8D 7B 01      STA    SUBR +
0345: 0531 8D 7B 01      STA    SUBR +
0346: 0532 8D 7B 01      STA    SUBR +
0347: 0533 8D 7B 01      STA    SUBR +
0348: 0534 8D 7B 01      STA    SUBR +
0349: 0535 8D 7B 01      STA    SUBR +
0350: 0536 8D 7B 01      STA    SUBR +
0351: 0537 8D 7B 01      STA    SUBR +
0352: 0538 8D 7B 01      STA    SUBR +
0353: 0539 8D 7B 01      STA    SUBR +
0354: 053A 8D 7B 01      STA    SUBR +
0355: 053B 8D 7B 01      STA    SUBR +
0356: 053C 8D 7B 01      STA    SUBR +
0357: 053D 8D 7B 01      STA    SUBR +
0358: 053E 8D 7B 01      STA    SUBR +
0359: 053F 8D 7B 01      STA    SUBR +
0360: 0540 8D 7B 01      STA    SUBR +
0361: 0541 8D 7B 01      STA    SUBR +
0362: 0542 8D 7B 01      STA    SUBR +
0363: 0543 8D 7B 01      STA    SUBR +
0364: 0544 8D 7B 01      STA    SUBR +
0365: 0545 8D 7B 01      STA    SUBR +
0366: 0546 8D 7B 01      STA    SUBR +
0367: 0547 8D 7B 01      STA    SUBR +
0368: 0548 8D 7B 01      STA    SUBR +
0369: 0549 8D 7B 01      STA    SUBR +
0370: 054A 8D 7B 01      STA    SUBR +
0371: 054B 8D 7B 01      STA    SUBR +
0372: 054C 8D 7B 01      STA    SUBR +
0373: 054D 8D 7B 01      STA    SUBR +
0374: 054E 8D 7B 01      STA    SUBR +
0375: 054F 8D 7B 01      STA    SUBR +
0376: 0550 8D 7B 01      STA    SUBR +
0377: 0551 8D 7B 01      STA    SUBR +
0378: 0552 8D 7B 01      STA    SUBR +
0379: 0553 8D 7B 01      STA    SUBR +
0380: 0554 8D 7B 01      STA    SUBR +
0381: 0555 8D 7B 01      STA    SUBR +
0382: 0556 8D 7B 01      STA    SUBR +
0383: 0557 8D 7B 01      STA    SUBR +
0384: 0558 8D 7B 01      STA    SUBR +
0385: 0559 8D 7B 01      STA    SUBR +
0386: 055A 8D 7B 01      STA    SUBR +
0387: 055B 8D 7B 01      STA    SUBR +
0388: 055C 8D 7B 01      STA    SUBR +
0389: 055D 8D 7B 01      STA    SUBR +
0390: 055E 8D 7B 01      STA    SUBR +
0391: 055F 8D 7B 01      STA    SUBR +
0392: 0560 8D 7B 01      STA    SUBR +
0393: 0561 8D 7B 01      STA    SUBR +
0394: 0562 8D 7B 01      STA    SUBR +
0395: 0563 8D 7B 01      STA    SUBR +
0396: 0564 8D 7B 01      STA    SUBR +
0397: 0565 8D 7B 01      STA    SUBR +
0398: 0566 8D 7B 01      STA    SUBR +
0399: 0567 8D 7B 01      STA    SUBR +
0400: 0568 8D 7B 01      STA    SUBR +
0401: 0569 8D 7B 01      STA    SUBR +
0402: 056A 8D 7B 01      STA    SUBR +
0403: 056B 8D 7B 01      STA    SUBR +
0404: 056C 8D 7B 01      STA    SUBR +
0405: 056D 8D 7B 01      STA    SUBR +
0406: 056E 8D 7B 01      STA    SUBR +
0407: 056F 8D 7B 01      STA    SUBR +
0408: 0570 8D 7B 01      STA    SUBR +
0409: 0571 8D 7B 01      STA    SUBR +
0410: 0572 8D 7B 01      STA    SUBR +
0411: 0573 8D 7B 01      STA    SUBR +
0412: 0574 8D 7B 01      STA    SUBR +
0413: 0575 8D 7B 01      STA    SUBR +
0414: 0576 8D 7B 01      STA    SUBR +
0415: 0577 8D 7B 01      STA    SUBR +
0416: 0578 8D 7B 01      STA    SUBR +
0417: 0579 8D 7B 01      STA    SUBR +
0418: 057A 8D 7B 01      STA    SUBR +
0419: 057B 8D 7B 01      STA    SUBR +
0420: 057C 8D 7B 01      STA    SUBR +
0421: 057D 8D 7B 01      STA    SUBR +
0422: 057E 8D 7B 01      STA    SUBR +
0423: 057F 8D 7B 01      STA    SUBR +
0424: 0580 8D 7B 01      STA    SUBR +
0425: 0581 8D 7B 01      STA    SUBR +
0426: 0582 8D 7B 01      STA    SUBR +
0427: 0583 8D 7B 01      STA    SUBR +
0428: 0584 8D 7B 01      STA    SUBR +
0429: 0585 8D 7B 01      STA    SUBR +
0430: 0586 8D 7B 01      STA    SUBR +
0431: 0587 8D 7B 01      STA    SUBR +
0432: 0588 8D 7B 01      STA    SUBR +
0433: 0589 8D 7B 01      STA    SUBR +
0434: 058A 8D 7B 01      STA    SUBR +
0435: 058B 8D 7B 01      STA    SUBR +
0436: 058C 8D 7B 01      STA    SUBR +
0437: 058D 8D 7B 01      STA    SUBR +
0438: 058E 8D 7B 01      STA    SUBR +
0439: 058F 8D 7B 01      STA    SUBR +
0440: 0590 8D 7B 01      STA    SUBR +
0441: 0591 8D 7B 01      STA    SUBR +
0442: 0592 8D 7B 01      STA    SUBR +
0443: 0593 8D 7B 01      STA    SUBR +
0444: 0594 8D 7B 01      STA    SUBR +
0445: 0595 8D 7B 01      STA    SUBR +
0446: 0596 8D 7B 01      STA    SUBR +
0447: 0597 8D 7B 01      STA    SUBR +
0448: 0598 8D 7B 01      STA    SUBR +
0449: 0599 8D 7B 01      STA    SUBR +
0450: 059A 8D 7B 01      STA    SUBR +
0451: 059B 8D 7B 01      STA    SUBR +
0452: 059C 8D 7B 01      STA    SUBR +
0453: 059D 8D 7B 01      STA    SUBR +
0454: 059E 8D 7B 01      STA    SUBR +
0455: 059F 8D 7B 01      STA    SUBR +
0456: 05A0 8D 7B 01      STA    SUBR +
0457: 05A1 8D 7B 01      STA    SUBR +
0458: 05A2 8D 7B 01      STA    SUBR +
0459: 05A3 8D 7B 01      STA    SUBR +
0460: 05A4 8D 7B 01      STA    SUBR +
0461: 05A5 8D 7B 01      STA    SUBR +
0462: 05A6 8D 7B 01      STA    SUBR +
0463: 05A7 8D 7B 01      STA    SUBR +
0464: 05A8 8D 7B 01      STA    SUBR +
0465: 05A9 8D 7B 01      STA    SUBR +
0466: 05A0 8D 7B 01      STA    SUBR +
0467: 05A1 8D 7B 01      STA    SUBR +
0468: 05A2 8D 7B 01      STA    SUBR +
0469: 05A3 8D 7B 01      STA    SUBR +
0470: 05A4 8D 7B 01      STA    SUBR +
0471: 05A5 8D 7B 01      STA    SUBR +
0472: 05A6 8D 7B 01      STA    SUBR +
0473: 05A7 8D 7B 01      STA    SUBR +
0474: 05A8 8D 7B 01      STA    SUBR +
0475: 05A9 8D 7B 01      STA    SUBR +
0476: 05A0 8D 7B 01      STA    SUBR +
0477: 05A1 8D 7B 01      STA    SUBR +
0478: 05A2 8D 7B 01      STA    SUBR +
0479: 05A3 8D 7B 01      STA    SUBR +
0480: 05A4 8D 7B 01      STA    SUBR +
0481: 05A5 8D 7B 01      STA    SUBR +
0482: 05A6 8D 7B 01      STA    SUBR +
0483: 05A7 8D 7B 01      STA    SUBR +
0484: 05A8 8D 7B 01      STA    SUBR +
0485: 05A9 8D 7B 01      STA    SUBR +
0486: 05A0 8D 7B 01      STA    SUBR +
0487: 05A1 8D 7B 01      STA    SUBR +
0488: 05A2 8D 7B 01      STA    SUBR +
0489: 05A3 8D 7B 01      STA    SUBR +
0490: 05A4 8D 7B 01      STA    SUBR +
0491: 05A5 8D 7B 01      STA    SUBR +
0492: 05A6 8D 7B 01      STA    SUBR +
0493: 05A7 8D 7B 01      STA    SUBR +
0494: 05A8 8D 7B 01      STA    SUBR +
0495: 05A9 8D 7B 01      STA    SUBR +
0496: 05A0 8D 7B 01      STA    SUBR +
0497: 05A1 8D 7B 01      STA    SUBR +
0498: 05A2 8D 7B 01      STA    SUBR +
0499: 05A3 8D 7B 01      STA    SUBR +
0500: 05A4 8D 7B 01      STA    SUBR +
0501: 05A5 8D 7B 01      STA    SUBR +
0502: 05A6 8D 7B 01      STA    SUBR +
0503: 05A7 8D 7B 01      STA    SUBR +
0504: 05A8 8D 
```

0570:
0580: IF SETUP WAS ENTERED WITH A = EA, THEN
0590: DO THE SETUP AND THEN INT THE VIDEO

0600: 0541 4C 58 00 VIDEO JMP TTABLE START WITH PROGRAM IN VIDEO MEMORY
0610: 0544 3A NCP
0620: 0545 5A NCP
0630: 0545 5A NCP
0640:
0650:
ID=

IF SETUP WAS ENTERED WITH A = EA, THEN
DO THE SETUP AND THEN INT THE VIDEO

TTABLE START WITH PROGRAM IN VIDEO MEMORY

INTC 00C8 INITD 00CE CURSOR 00F0
INTC 00F4 LRT 00F6 HRT 00F7
INITE 0103 UIN 0108 INITF 0109 CLR 0121
FINI 0136 FINIS 0137 COLROW 0139 SNDLDP 015F
CURPRM 0170 CURPC 0171 COLMAX 0172 CRLFTV 0172
RAMPAG 0173 RAMEND 0174 ASK 0175 LSUB 0176
HSUB 0177 JUMP 0178 CRTVC 0179 SUPER 017B
JFLAG 017E XTEMP 017F YTEMP 0180 LCHAR 0181
CRTVI 0182 CRTVS 018E CURRIG 0195 OUTTV 019F
OUTNXT 01BE NY 01CB TGL 01D1 NXX 01D9
NAA 01E1 NWW 01E9 EOS 01ED HOMAX 01FE
NTT 0200 HCMEX 0206 N22 020A KIMST 0223
TSTAS 0231 SYMTST 0233 SYMLF 0235 SYMX 023C
KIMDEL 0240 AIMTST 0247 ENTCHR 0248 ENTCHA 0253
STCHB 0255 HOME 0257 HOMA 025C CLRSR 026C
RIGHT 0278 DOWN 027A UP 027C LEFT 027E
SCROLL 0280 SCRA 0285 SCRIB 0291 SETEND 0242
LFEED 02B4 CURDOW 02C2 CURUP 02D6
CURITZ 02EA CRX 02F5 CURLEF 02FD HOMAXX 0305
HOMECU 030A SPACES 0317 STORE 0321 STCHR 0337
XXA 0342 STCHAA 0352 XKB 035E STCHA 0361
STCHB 0365 STCHC 0369 STCHD 036B STCHS 0377
TRANSF 0378 SYMDEL 0395 DELETE 0399 XXC 03A2
SPSL 03A8 DELA 03B6 SDELA 03CD DECREM 03DA
DESCRA 03B2 DECRB 03E4 TABLE 03ED KBINIT 0400
KIMA 041E KBDA 0427 KIMB 0442 KBDB 044C
KBDC 0452 INDONE 0478 KBTEST 047D NODATA 048A
KNDONE 048D KBWATT 048E KBGET 049A KNORM 04B7
NOTUP 04C8 AVOUT 04D3 ECHO 04DC ALLST 04E5
UCUT 04EA ALLOCUT 04F1 KIMCUT 04F2 SETUP 0500
BREAK 0540 VIDEO 0541 ACCESS 8B86 NACCES 8B9C
DILINK A406 CURPOZ A415 DIBUFF A438 TECNO A653
INVEC A660 CUTVEC A663 INSVEC A666 COMIN E1A1

SYMBOL TABLE 2000 237E

KOTT 0000 JRTN 0000 KTST 0002 KIN 0004
SRTN 0005 JDONE 0048 JSOUT 0054 TABLE 0058
USER 0067 TLCCP 007F TDONE 008D SETAK 009B
SETASK 00A1 INIT 00B1 INITA 00B5 INITB 00BF
INTC 00C8 INITD 00CE CURSOR 00F0 CRTREG 00F2
INTC 00F4 LRT 00F6 HRT 00F7 INITK 00F8
INITE 0103 UIN 0108 INITF 0109 CLR 0121
FINI 0136 FINIS 0137 COLROW 0139 SNDLDP 015F
CURPRM 0170 CURPC 0171 COLMAX 0172 CRLFTV 0172
RAMPAG 0173 RAMEND 0174 ASK 0175 LSUB 0176
HSUB 0177 JUMP 0178 CRTVC 0179 SUPER 017B
JFLAG 017E XTEMP 017F YTEMP 0180 LCHAR 0181
CRTVI 0182 CRTVS 018E CURRIG 0195 OUTTV 019F
OUTNXT 01BE NY 01CB TGL 01D1 NXX 01D9
NAA 01E1 NWW 01E9 EOS 01ED HOMAX 01FE
NTT 0200 HCMEX 0206 N22 020A KIMST 0223
TSTAS 0231 SYMTST 0233 SYMLF 0235 SYMX 023C
KIMDEL 0240 AIMTST 0247 ENTCHR 0248 ENTCHA 0253
STCHB 0255 HOME 0257 HOMA 025C CLRSR 026C
RIGHT 0278 DOWN 027A UP 027C LEFT 027E
SCROLL 0280 SCRA 0285 SCRIB 0291 SETEND 0242
LFEED 02B4 CURDOW 02C2 CURUP 02D6
CURITZ 02EA CRX 02F5 CURLEF 02FD HOMAXX 0305
HOMECU 030A SPACES 0317 STORE 0321 STCHR 0337
XXA 0342 STCHAA 0352 XKB 035E STCHA 0361
STCHB 0365 STCHC 0369 STCHD 036B STCHS 0377
TRANSF 0378 SYMDEL 0395 DELETE 0399 XXC 03A2
SPSL 03A8 DELA 03B6 SDELA 03CD DECREM 03DA
DESCRA 03B2 DECRB 03E4 TABLE 03ED KBINIT 0400
KIMA 041E KBDA 0427 KIMB 0442 KBDB 044C
KBDC 0452 INDONE 0478 KBTEST 047D NODATA 048A
KNDONE 048D KBWATT 048E KBGET 049A KNORM 04B7
NOTUP 04C8 AVOUT 04D3 ECHO 04DC ALLST 04E5
UCUT 04EA ALLOCUT 04F1 KIMCUT 04F2 SETUP 0500
BREAK 0540 VIDEO 0541 ACCESS 8B86 NACCES 8B9C
DILINK A406 CURPOZ A415 DIBUFF A438 TECNO A653
INVEC A660 CUTVEC A663 INSVEC A666 COMIN E1A1

SYMBOL TABLE 2090 2373

ACCESS	6B66	ATTEST	0247	ALLOCUT	04F1
ASK	0175	AUCUT	04D5	BREAK	0540
CLR	0121	COLMAX	0172	COLROW	0139
CRLEFTV	0172	CRTREG	00F2	CRTVT	0182
CRPTVS	0165	CRX	02F5	CURDA	02D1
CURITE	028A	CURLEF	02FD	CURPCZ	A415
CURPARM	0170	CURRIG	0195	CURSCR	026C
DECRA	03E2	DECRRB	03E4	CURUP	02D6
DELETA	0399	DIBUFF	A436	DECREM	03DA
DSPECIFIC	EF05	ECHO	04DC	DJLINK	A406
ENTCHR	024E	ECS	01ED	ENTCHA	0253
HOMA	025C	HOMAX	01FE	FINI	0136
HOMECU	030A	HOMEX	0296	HOMAXX	0305
INDONE	0478	JNTT	0CB1	HRT	00F7
INFTC	00C6	TINTD	00CE	INITA	00B5
INFTK	00F6	INSVEC	A666	INITB	00BF
JFLAG	0173	JRTN	000C	INITE	0103
KBDA	0427	KBDB	044C	INVEC	A660
KBTANT	0400	KBTTEST	047D	JSCUT	0054
KIMB	0442	KIMDEL	0240	KBDC	0452
KIN	0004	KMDONE	048D	KBGET	0494
KIST	0002	LCHAR	0181	KBWAIT	0465
LRT	00F6	LSUB	0176	KIMA	041E
NCDATA	048A	NOTUP	04C8	KIMOUT	04F2
NXX	01D9	NYX	01CB	KNORM	04B7
CUTTV	019F	CUTVEC	A663	RAMEND	0174
RIGHT	0276	SCRA	0285	SCRLW	027E
SCROLL	0260	SDEL	03A6	SDELA	03CD
SETASK	00A1	SETEND	02A2	SETUP	0520
SPACES	0317	SRTN	0005	STCHA	0361
STCHB	0365	STCHC	0369	STCHD	036B
STCHR	0337	STCRE	0321	SUBR	017B
SYMLF	0235	SYMTST	0233	SYMX	023C
TDONE	00BD	TECHO	A653	TGL	01D1
TRANSF	0376	TSTAS	0231	TTABLE	0058
UCUT	04EA	UP	027C	USER	0067
XTEMP	017F	XXA	0342	XXB	035E
YTEMP	0160			XXC	03A2