


# Z80 Microprocessor Kit

## User's manual



# Z80 MICROPROCESSOR KIT USER'S MANUAL

## CONTENTS


OVERVIEW.....	3
FUNCTIONAL BLOCK DIAGARM.....	3
HARDWARE LAYOUT.....	4
KEYBOARD LAYOUT.....	5
HARDWARE FEATURES.....	6
MEMORY AND I/O MAPS.....	6
GPIO1 LED.....	7
CONNECTING Z80 KIT TO TERMINAL.....	8
EXPANSION BUS HEADER.....	9
10ms TICK GENERATOR.....	10
RS232C PORT.....	11
DATA FRAME for UART COMMUNICATION.....	11
CONNECTING LCD MODULE.....	12
LOGIC PROBE POWER SUPPLY.....	12
HARDWARE SCHEMATIC, BOM, AND PCB LAYOUT.....	13

## OVERVIEW

The Z80 microprocessor kit is a single board microcomputer designed for self learning. Students will learn how to build the computer using the 1976, Z80 microprocessor with memory and simple I/O chips. The kit can be assembled at home without the need of special tools. The kit itself is the real microcomputer. Students will learn how to program the Z80 microprocessor in machine language with instruction hex code. The hex code can be entered to memory and tested it directly. Results of CPU operations can be checked in the memory or user registers display easily.

The kit manuals are 1) user's manual for hardware details, 2) programming lab book and 3) construction guide for kit assemble steps.


### Z80 KIT FUNCTIONAL BLOCK DIAGRAM



#### Notes

1. UART is software control for low speed asynchronous communication.
2. LCD module is optional, the kit provides a 16-pin header.
3. 10ms Tick generator is for a maskable interrupt source. NMI is used by single stepping circuit.

## HARDWARE LAYOUT



### Important Notes

1. Plugging or removing the LCD module must be done when the kit is powered off!
2. AC adapter should provide approx. +9VDC, higher voltage will cause the voltage regulator chip, U9 becomes hot.
3. The kit has diode protection for wrong polarity of adapter jack. If the center pin is not the positive (+), the diode will reverse bias, preventing wrong polarity to feed to voltage regulator.

## KEYBOARD LAYOUT

COPY	SZxH	xPNC	SZxH'	xPNC'	PC	SBR	INS	RESET
	C	D	E	F				
REL	IX	IY	SP	IxIF	REG	CBR	DEL	MON
	8	9	A	B				
SEND	AF'	BC'	DE'	HL'	DATA	—	STEP	INTR
	4	5	6	7				
LOAD	AF	BC	DE	HL	ADDR	+	GO	USER
	0	1	2	3				

**HEX keys** Hexadecimal number 0 to F with associated user registers and flag bits when press REG

### CPU control keys

**RESET** Reset the CPU, Z80 will begin fetch the code from location 0000  
**MON** Force CPU to jump back to monitor program  
**INTR** Make INT pin to logic low, used for experimenting with interrupt process  
**USER** User key for lab test, active low

### Monitor function keys

**INS** Insert byte to memory, current byte will be shifting down.  
**DEL** Delete current byte, the next byte will be shifting up.  
**STEP** Execute user code only single instruction and return to save CPU registers  
**GO** Jump from monitor program to user code  
**SBR** Set break address  
**CBR** Clear break address  
**PC** Set current display address with user Program Counter  
**REG** Display user registers or flags with HEX key for a given register.  
**DATA** Set entry mode of hex keys to Data field  
**ADDR** Set entry mode of hex keys to Address field


- COPY**      Copy block of memory, used with key + for Start, End, Destination and key GO
- REL**        Compute relative byte, used with key + for Start, Destination and key GO
- SEND**      Send Intel hex file at 2400 bit/s using serial port
- LOAD**      Load Intel hex file at 2400 bit/s using serial port

### HARDWARE FEATURES

- **Microprocessor: Zilog Z80 @1.79MHz, 40-pin DIP package**
- **Memory: 4kB monitor ROM, 32KB user RAM**
- **Memory& I/O Decoder logic: GAL16V8**
- **System tick: 10ms produced by AT89C2051 microcontroller**
- **GPIO: 8-bit LED display**
- **DISPLAY: 6-digit super bright 7-segment display**
- **Keypad: 36-key**
- **Serial port: 2400 Bit/s RS232C using software controlled UART**
- **Expansion slot: 40-pin header**
- **LCD bus: 16x2 text display direct bus interface**


### MEMORY AND I/O MAP

The Z80 kit has separated memory and I/O space. Memory space is selected with MREQ signal, I/O space with IORQ signal. The bank areas for both memory and I/O are available for experimenting.



## GPIO1 LED

The Z80 kit provides a useful 8-bit binary display. It can be used to debug the program or code running demonstration. The I/O address is 40H. U16 is 8-bit data latch. Logic 1 at the output will make LED lit.



The GPIO1 LED can be used to display accumulator register easily. Let us take a look the sample code below.

Address	Hex code	Label	Instruction	comment
1800	3E 01	MAIN	LD A,1	Load register A with 1
1802	D3 40		OUT (40H),A	Write A to GPIO1@ 40H

The test code has only two instructions. Each instruction has machine code of two bytes. Enter the hex code to memory from 1800 to 1803. Then press PC, and execute the instruction with single step by pressing key STEP. The 2<sup>nd</sup> pressed STEP key that executes instruction out (40H),A will make the GPIO1 LED showing the content of register A.

Another sample is with JUMP instruction. The JUMP instruction will change the Program Counter to 1800, to repeat program running.

Address	Hex code	Label	Instruction	comment
1800	3C	MAIN	INC A	Increment register A
1801	D3 40		OUT (40H),A	Write A to GPIO1@ 40H
1803	C3 00 18		JP MAIN	Jump back to main

Again enter the hex code to memory and test it with single step. Every time when instruction out(40H),A was executed, did you see the LED display changed?

We will learn more the use of GPIO1 with Z80 Programming Lab Book.


## CONNECTING Z80 KIT TO TERMINAL

All of monitor commands are compatible with MPF-1, except SEND and LOAD keys. For LOAD key, we can connect the Z80 kit to a terminal by RS232C cross cable. You may download free terminal program, teraterm from this URL, <http://tssh2.sourceforge.jp/index.html.en>



The example shows connecting laptop with COM1 port to the RS232C port of the Z80 kit.

To download Intel hex file that generated from the assembler or c compiler, **set serial port speed to 2400 bit/s, 8-data bit, no parity, no flow control, one stop bit.**




Press key LOAD, then key GO. The kit will wait for the data stream from terminal. On PC, Click file>Send File>LED.HEX. The kit will read the hex file, write to memory, when completed the start message will be displayed.

SEND key will need Start, End address then press GO, the kit will send Intel hex file to terminal.


### EXPANSION BUS HEADER

JP1, 40-pin header provides CPU bus signals for expansion or I/O interfacing. Students may learn how to make the simple I/O port, interfacing to Analog-to-Digital Converter, interfacing to stepper motor or AC power circuits.




### USER KEY

User key, S19 is one bit active low key switch connected to bit 6 of Port 0. To test the logic of S19, we can use IN A,(0) and check bit 6 of the accumulator with test bit instruction.



## 10ms TICK GENERATOR

SW4 is a selector for interrupt source between key INTR or 10ms tick produced by 89C2051 microcontroller. Tick generator is software controlled using timer0 interrupt in the 89C2051 chip. The active low tick signal is sent to P3.7. For tick running indicator, P1.7 drives D15 LED.




Tick is a 10ms periodic signal for triggering the Z80 interrupt pin. When select SW4 to Tick, the Z80 CPU can be triggered by a maskable interrupt. The 100Hz tick or 10ms tick can be used to produce tasks that executed with multiple of tick. The Z80 kit lab look will show how to use 10ms tick to make a digital timer.



## RS232C PORT

The RS232C port is for serial communication. We can use a cross cable or null MODEM cable to connect between the kit and terminal, or kit #1 to kit #2 for sending or receiving hex file. The connector for both sides are DB9 female. We may build it or buying from computer stores.




For new PC or laptop computer with USB port, we may have the RS232C port by using the USB to RS232 converter.



## DATA FRAME for UART COMMUNICATION

Serial data that communicated between kit and terminal is asynchronous format. The Z80 kit has no UART chip, instead it uses software controlled to produce bit rate of 2400 bit/s. The data frame is composed of start bit, 8-data bit and stop bit. For our kit, period =  $1/2400 = 417$  microseconds.



Since bit period is provided by machine cycle delay. Thus to send/receive serial data correctly, all interrupts must be disabled.

## CONNECTING LCD MODULE

JR1 is 20-pin header for connecting the LCD module. The example shows connecting the 16x2 lines text LCD module. R17 is a current limit resistor for back-light. R18 is trimmer POT for contrast adjustment. The LCD module is interfaced to the Z80 bus directly. The command and data registers are located in I/O space having address from 80H to 83H.



*Be advised that plugging or removing the LCD module must be done when the kit is powered off.*

Text LCD module accepts ASCII codes for displaying the message on screen.

Without settings the LCD by software, no characters will be displayed. The first line

will be black line by adjusting the R18 for contrast adjustment.


## LOGIC PROBE POWER SUPPLY

The kit provides test points TP1(+5V) and TP2(GND) for using the logic probe. Students may learn digital logic signals with logic probe easily. The important signals are RESET (TP4) and CPU clock (TP3). Tick signal, however indicated by D15 LED blinking. Logic probe can test it at P3.7 of the 89C2051 microcontroller directly. Red clip is for +5V and Black clip for GND.





# **HARDWARE SCHEMATIC, PARTS LIST AND PCB LAYOUT**








Title		Z80 TRAINER KIT
Size		Document Number
Date		<Doc>
Rev	Sheet	2 of 3
2		



16x2 text LCD interface



8-bit Binary display LED x8



Title		Z80 TRAINER KIT
Size	Document Number	<Doc>
Date	Saturday, January 17, 2015	Sheet 3 of 3
Rev		1

## PARTS LIST

### Semiconductors

U1	Z80 40-pin DIP microprocessor
U2	27C64 or 27C256 EPROM
U3	HM62256B 32kB SRAM
U4	74LS14 inverter
U5	74HC74 Dual D-type flip-flop
U6	GAL16V8B programmable logic device
U7	74LS90 decade counter
U8	AT89C2051 20-pin microcontroller
U9	LM7805/TO voltage regulator
U11,U10	LTC-4727JR 4-digit 7-segment LED
U12,U14,U16	74HC573 8-bit latch
U13	CD4001 quad NOR gate
U15	74HC541 tri-state buffer
U17	MAX232A rs232 converter
D1,D6,D7,D8,D9,D10,D11,	3mm LED
D12,D13,D15	
D2	TVS5V_SOD123 transient voltage suppressor
D4	1N4007 rectifying diode
D14	1N5226A +3.3V zener 500mW
Q2,Q1	BC557 PNP transistor
D3	POWER 3mm LED
D5	TONE 3mm LED

### Resistors (all resistors are 1/8W +/-5%)

R1,R2,R9	1k
R3,R4,R5,R6,R8,R18	10K
R7,R19	680 Ohms
R10	2k
R16,R12	10k RESISTOR SIP 9
R13	4.7k
R14	330 Ohms
R17,R15	10 Ohms



### Capacitors

C1	100pF ceramic
C2,C3,C15,C16,C17	10uF electrolytic
C4	100uF electrolytic
C5	10uF 16V electrolytic
C6	1000uF 16V electrolytic
C7,C8,C9,C10,C11	0.1uF multi layer
C12,C13	0.1uF multilayer
C14	10uF 10V electrolytic
C18	0.1uF multilayer

### Additional parts


JP1	HEADER 20X2
JR1	CONN RECT 16 pins
J1	DC input JACK
J2	HEADER 3 pins
LS1	8 Ohms SPEAKER
SW1	RESET 12mm tact switch
SW2	INTR 12mm tact switch
SW3	MONITOR 12mm tact switch
SW4	slide switch-SPDT
S1,S2,S3,S4,S5,S6,S7,S8,	12mm TACT switch
S9,S10,S11,S12,S13,S14,	
S15,S16,S17,S18,S19,S20,	
S21,S22,S23,S24,S25,S26,	
S27,S28,S29,S30,S31,S32,	
S33	
VB1	DB 9, Male connector
Y1	XTAL 3.579MHz
PCB	double side plate through hole
LED cover	Clear RED color acrylic plastic
Keyboard sticker	printable SVG file

# SILK SCREEN TOP LAYER




Z80 MICROPROCESSOR KIT

TOP LAYER



BOTTOM LAYER



## NOTE